

**Aristel™**

# System Programming Manual

FOR ALL AV-SERIES SYSTEMS

Aristel Group

## INSIDE

System Timing Parameter

System Function Parameter

System Function - 1

System Function - 2

Station Function

CO Function

*AV-Series System Programming Man*

*The Best In Telecommunications*

# CONTENTS

## **PROGRAMMING INITIALIZATION..... 0-1**

**INTRODUCTION: ..... 0-1**

**SYSTEM PROGRAMMING: ..... 0-1**

**ENTERING SYSTEM PROGRAMMING ..... 0-1**

On Hook Programming ..... 0-1

On Call Programming ..... 0-1

**ENTERING PROGRAMMING HELP LIST ..... 0-3**

## **SYSTEM PROGRAMMING..... 1-1**

**SYSTEM TIMING PARAMETER (ZONE 100 ~ 199) ..... 1-1**

100 Pause Time ..... 1-1

101 DTMF Generation Time..... 1-1

102 SLT Release Time..... 1-1

103 SLT Hold Time ..... 1-2

104 Ring On Time ..... 1-2

105 Ring Off Time ..... 1-3

106 Flash Time for Key Phone & Overriding Flash Time for

PSTN Line ..... 1-3

107 Hold Recall Time ..... 1-4

108 Hold Recall Timeout ..... 1-4

109 Exclusive Hold Recall Time ..... 1-4

110 Exclusive Hold Recall Timeout..... 1-5

111 SLT Dial Tone Timeout.....1-5

112 SLT Inter-Dialing Timeout .....1-6

113 Transfer Busy Recall Timeout.....1-6

114 Transfer No Answer Recall Timeout .....1-6

115 CFW No Answer Transfer Time.....1-6

116 DISA No Answer Transfer Time.....1-7

117 DISA No Dialing Transfer Time.....1-7

118 DISA Enable Delay Time 1 .....1-7

119 DISA Engaged Time .....1-7

120 Auto Redial Waiting Time (On Hook).....1-8

121 Auto Redial Pause Time (Off Hook).....1-8

122 Busy Reminder Interval Time.....1-8

123 Incoming Hunt Ring Time .....1-9

124 Door Sensor Detection Ringing Time .....1-9

125 Busy Tone On (I) Detection Time .....1-9

126 Busy Tone Off (I) Detection Time .....1-10

127 Busy Tone On (II) Detection Time .....1-10

128 Busy Tone Off (II) Detection Time .....1-10

129 CO Delay Time .....1-11

130 CO Access Delay Time.....1-11

131 Door Ringing Delay Time.....1-11

132 Metering Pulse Delay Time.....1-11

133 DISA Console Transferring Time .....1-12

134 Incoming Delay Time .....1-12

**SYSTEM TIMING PARAMETER (ZONE 100 ~ 199) .....1-1**

135	The 2nd DSS Page Remaining Time or SLT MSG Wait Silence Time.....	1-12
136	SOS Enable Delay Time or SLT MSG Wait Ringing Time .....	1-13
137	Metering Pulse Detection Starting Time .....	1-14
138	Metering Pulse Detection Ending Time .....	1-14
139	ACD Enable Time.....	1-14
140	DISA Enable Delay Time 2.....	1-15
141	DISA Enable Delay Time 3.....	1-15
142	DISA Enable Delay Time 4.....	1-15
143	Door Call Ringing Time .....	1-16
144	System Wide FWD Time .....	1-16
145 ~ 149	Reserved for the Future Use .....	1-16

#### **SYSTEM FUNCTION PARAMETER (ZONE 200 ~ 299)..... 2-1**

200	PABX (Centrex) Outgoing Code.....	2-1
201	Operator Code.....	2-1
202	Dial_9 CO Code .....	2-1
203	Toll Code.....	2-2
204	12/24 Hour Clock.....	2-2
205	Station Number Digit Length .....	2-2
206	Digit Length for Local Call .....	2-2
207	Intercom Calling Type .....	2-3
208	Intercom Dial Tone Signalling.....	2-3
209	Intercom One Digit Dialing Capability.....	2-3
210	Intercom Hunting.....	2-4
211	Wake Up Call Signalling.....	2-4
212	Message Wait Auto Ringing .....	2-4
213	Make/Break Ratio.....	2-5

214	Automatic CO Search .....	2-5
215	Dial_9 Capability.....	2-5
216	CO Delay Capability/Paging Tone of 15 Keys KP.....	2-6
217	Mute CO Capability.....	2-6
218	DISA Recall Capability.....	2-6
219	DISA Transfer Group Capability .....	2-7
220	Fax Monitoring Capability .....	2-8
221	Busy Tone Detection/Hold Reminder Capability .....	2-8
222	DSS Keys for Different CO Group .....	2-9
223	Auto-Redial Times .....	2-9
224	Limit Call Pattern .....	2-10
225	Speed Dial Distribution .....	2-10
226	Speed Dial Unrestricted Range .....	2-11
227	Name Speed Dial Capability .....	2-11
228	SMDR Masked Capability .....	2-12
229	Busy Reminder Capability.....	2-12
230	Link Monitor Capability.....	2-12
231	Volume-Initial Setting .....	2-13
232	Speed Dial Pause Times .....	2-13
233	Busy Tone Detection Times.....	2-13
234	CO Auto-Transfer Capability.....	2-14
235	System Programming Password Protection.....	2-14
236	Dial Tone Detection Times.....	2-15
237	SLT Pulse Dialing Operation Code with [#]/[ * ] .....	2-15
238	DISA Single Digit Dialing Capability.....	2-15
239	Do Not Disturb Capability.....	2-16

#### **SYSTEM FUNCTION PARAMETER (ZONE 200 ~ 299).....2-1**

240	Auto-Accessing CO Line Capability .....	2-16
-----	---	------

241	Direct Intercom Dialing & FAC Uninhibited by Call Limit Duration Capability .....	2-16
242	Exclusive Hold & System Wide CFW Capability.....	2-17
243	SOS Outgoing-Playing Times.....	2-17
244	Door Phone Ringing Capability .....	2-18
245	SLT & Voice Mail Message Waiting Function Capability Time.....	2-18
246	Voice Recording Copy Capability .....	2-19
247	Background Music for CO Incoming Ringing Signal Capability.....	2-19
248	Call Forward Function Capability.....	2-19
249	Ringling Signal for Door Phone Call.....	2-20
250	Capability of Console Entering System SPD/Name SPD/Alarm.....	2-20
251	Metering Detection Capability or RS232 Modem Capability.....	2-20
252	Limit Month Function .....	2-21
253	Special Warning Tone During HF/Override/Conference Capability.....	2-21
254	The Way for SLT to Put the Call On Hold Capability ....	2-22
255 ~ 299	Reserved For Future Use.....	2-22
<b>SYSTEM FUNCTION - 1 (ZONE 300 ~ 399) .....</b>		<b>3-1</b>
300	Reset Data to Default .....	3-1
301	System Password Setup .....	3-1
302	Relay Function .....	3-2
303	Sensor Function .....	3-3
304	Date And Time .....	3-4
305	System Alarm Clock .....	3-5

306	Day Time Schedule .....	3-5
307	SMDR Report .....	3-6
308	Midday Time .....	3-7
309 ~ 399	Reserved For Future Use .....	3-8
<b>SYSTEM FUNCTION - 2 (ZONE 400 ~ 499) .....</b>		<b>4-1</b>
400	Console Arrangement .....	4-1
401	One Digit Dialing (ODD) Function .....	4-2
402	Voice Service .....	4-2
403	Forced Account Code (FAC).....	4-4
404	Speed Dial Code Assignment .....	4-4
405	Toll Group Assignment .....	4-5
406	Common Allowed Code .....	4-6
407	Common Disallowed Code .....	4-6
408	Area Code - A .....	4-7
409	Area Code - B .....	4-7
410	Office Code - A .....	4-8
411	Office Code - B .....	4-8
412 ~ 499	Reserved For Future Use .....	4-9
<b>STATION FUNCTION (ZONE 500 ~ 599).....</b>		<b>5-1</b>
500	Key Group Assignment (For KP) .....	5-1
501	Key Group Assignment (For DSS) .....	5-1
502	Station Function - Port Parameter .....	5-5
503	Station Function - Grouping .....	5-7
504	Station Function - Station Level .....	5-8
<b>STATION FUNCTION (ZONE 500 ~ 599).....</b>		<b>5-1</b>
505	Station Function - General Function 1 .....	5-10
506	Station Function - General Function 2 .....	5-11

507	Station Function - General Function 3.....	5-12
508	Station Function - Hot Line.....	5-13
509	Station Function - Individual SPD Block.....	5-14
510 ~ 599	Reserved For Future Use.....	5-15

## **CO FUNCTION (ZONE 600 ~ 699) ..... 6-1**

600	Incoming Ringing Assignment - Day Time .....	6-1
601	Incoming Ringing Assignment - Night Time.....	6-2
602	Door Ring Assignment .....	6-2
603	CO Group Assignment .....	6-3
604	CO Function Assignment .....	6-3
605	CO Lock .....	6-6
606	CO Incoming Ringing Frequency Assignment.....	6-6
607	Single Digit Group For DISA Dialing.....	6-7
608	Incoming CO Line Group.....	6-7
609	Voice Channel For Different CO Line .....	6-7
610	ISDN DID Number.....	6-8
611	ISDN DID Station Lookup.....	6-8
612	ISDN Termination.....	6-9
613	ISDN Type.....	6-9
614 ~ 699	Reserved For Future Use.....	6-9

## Programming Initialization

### Introduction:

There are six different programming zone groups contained in the system. This section details, in easy to follow instruction, the information necessary to program the system.

### System Programming:

Access to the system programming zone is restricted to personnel with the "Programming Password". Because it can check the programming steps and information during the programming only **LCD Key Phones** can be used for programming. The programming functions are represented by the following six (6) programming zone groups.

- **Zone Group 1 (Zone Number 100 ~ 199):**  
System Timing setting. The timing is defined as a unit. A total of 255 units can be selected.
- **Zone Group 2 (Zone Number 200 ~ 299):**  
System Parameter Setting.
- **Zone Group 3 (Zone Number 300 ~ 399):**  
System Function - 1 setting.
- **Zone Group 4 (Zone Number 400 ~ 499):**  
System Function - 2 settings.
- **Zone Group 5 (Zone Number 500 ~ 599):**  
Station Function setting.
- **Zone Group 6 (Zone Number 600 ~ 699):**  
CO Function setting.

### Entering System Programming

#### ■ On Hook Programming

Step 1. On Hook.

- Step 2. Press [FUNC] + [#]. System will ask for Programming Password.
- Step 3. Enter Programming Password. (If password in Program Zone 301-01 is "dd... " then ignore this step.)
- Step 4. Press [SAVE].
- Step 5. If the system denies the password a continuous tone will be heard. Press [SPK] to quit the programming status and restart from Step 2. If the system accepts the password you can now enter the system programming and the LCD phone will display the following message.
- Step 6. Enter the zone number in which you wish to set the data.
- Step 7. Press [SAVE] to confirm the setting data and it will be stored in the system memory. The programming will go on to the next step automatically.
- Step 8. Press [FUNC] key at any time to return to the main message.

**NOTE 1:**

1. The current programming status will be displayed on LCD.
2. There are 16 characters divided by two (2) lines in LCD display. The upper line is the PROGRAMMING STATUS AREA. The lower line is the SETTING DATA AREA.


#### ■ On Call Programming

- Step 1. During the call press [SPD] key.
- Step 2. Repeat from Step 2 in "On Hook Programming".

## INITIALIZATION

### Function Keys During System Programming


#### ● 15 Buttons Key Telephone



#### **Function Keys    Function Illustration**

[DSS1]	Back to the previous Program Zone
[DSS2]	Forward to the next Program Zone.
[DSS3]	Shifts cursor left.
[DSS4]	Shifts cursor right.
[DSS5]	Changes the Function Condition for the DSS key in Key Group Assignment.
[DSS6]	Help List.
[DSS10]	Clears all digits to be blank (or "d") in the current zone area.
[DSS11]	Saves the setting data to the system memory.
[DSS12]	Clear the current digit to "T" (Tone).
[DSS13]	Clear the current digit to "p" (Pause).
[DSS14]	Clear the current digit to "d" (Do Not Care).
[DSS15]	Clear the current digit to "_" (or "F") (Inhibit).

#### ● 25 Buttons Key Telephone



#### **Function Keys**

#### **Function Illustration**

[DSS1]	Back to the previous Program Zone
[DSS2]	Forward to the next Program Zone.
[DSS3]	Shifts cursor left.
[DSS4]	Shifts cursor right.
[DSS5]	Changes the Function Condition for the DSS key in Key Group Assignment.
[DSS10]	Clears all digits to be blank (or "d") in the current zone area.
[DSS15]	Clear the current digit to "_" (or "F") (Inhibit).
[DSS20]	Clear the current digit to "d" (Do Not Care).
[DSS21]	Help List.
[DSS23]	Clear the current digit to "P" (Pause).
[DSS24]	Clear the current digit to "T" (Tone).
[DSS25]	Saves the setting data to the system memory.

## Entering Programming Help List

The Programming Help List is to help users review each programming zone if the zone function is forgotten or the Programming Manual is not available. During Help List the name of the zone and the programming status will be displayed on the LCD display for three (3) seconds before moving to the next zone number automatically.

- Step 1. On Hook.
- Step 2. Press [FUNC] + [#] + [DSS21] to enter Programming Help List.
- Step 3. Press [SAVE] key during Help List for direct access to the system programming in the same zone area. The system data can then be programmed.

## Function Keys During Programming Help List

- **15 Buttons Key Telephone**

<u>Function Keys</u>	<u>Function Illustration</u>
----------------------	------------------------------

[DSS1]	Back to the previous Zone Group.
[DSS2]	Forward to the next Program Zone Group.
[DSS3]	Back to the previous Zone Number.
[DSS4]	Forward to the next Zone Number.

- **25 Buttons Key Telephone**

<u>Function Keys</u>	<u>Function Illustration</u>
----------------------	------------------------------


[DSS1]	Back to the previous Zone Group.
[DSS2]	Forward to the next Program Zone Group.
[DSS3]	Back to the previous Zone Number.
[DSS4]	Forward to the next Zone Number.



## System Programming

### ■ System Timing Parameter (Zone 100 ~ 199)

#### 100Pause Time



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=020=20x40=800 ms  
 <-- SSS=000~255  
 Def.=020=20x40=800 ms


#### Description:

A Pause Time is a time duration for a temporary pause. The letter "p" is the representative icon and is displayed in the LCD of the Key Phone when "PAUSE" key<sub>NOTE 2</sub> is pressed during outgoing dialing. Commonly used in Speed Dial, Redial and Auto Redial functions. When an outgoing call is made using Speed Dial, Redial or Auto Redial, the system will automatically display a Pause Setting Time if "p" is used in the dialing digits.

**NOTE 2:** 1. During outgoing dialing, "p" = [FUNC] key.  
 2. During System Speed Dial programming, "p" = [DSS23] key.

Interrelation Zones: Program Zones 232 and 404

#### 101 DTMF Generation Time




<-- Program Status Area  
 <-- SSS=000~255  
 Def.=055=55x2=110 ms

#### Description:

DTMF Generation Time is the length of time needed to generate a DTMF signal for each outgoing dialing digit under DTMF or Tone (T) dialing mode.

Interrelation Zones: Program Zone 604-CO-2=1

#### 102 SLT Release Time



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=150=150x6=900 ms

#### Description:


SLT Release Time is a time length of ON-HOOK or HOOK FLASH to indicate the disconnection status for Single Line Telephone (SLT). If the ON-HOOK or HOOK FLASH meets, or exceeds the setting time the call will then be disconnected immediately, and if shorter than SLT Release Time

## INITIALIZATION

but greater than SLT Hold Time (Program Zone 103) the call will be put into Hold status automatically.

Interrelation Zone: Program Zone 103


### 103 SLT Hold Time



<-- Program Status Area  
<-- SSS=000~255  
Def.=020=20x6=120 ms

#### Description:

SLT Hold Time is the duration time for ON-HOOK or HOOK-FLASH to indicate the hold status for Single Line Telephone (SLT). If the duration time of ON-HOOK or HOOK-FLASH meets, or exceeds the setting time, but is shorter than SLT Release Time (see Program Zone 102) the call will be placed into Hold status; but if shorter than the setting time then no action will occur or maybe become a pulse digit.




- **On Hook A or Hook-Flash A:** No action (retain existing status) or

maybe become a pulse digit.

- **On Hook B or Hook-Flash B:** The call will be held.
- **On Hook C or Hook-Flash C:** The call will be disconnected.

Interrelation Zone: Program Zone 102

### 104 Ring On Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=006=6x40=240 ms

#### Description:

Ring On Time is the minimum duration of the Incoming Ringing signal. If the system detects it steady on the CO line audio path as the setting time then it will be recognized by the system as a Real Incoming Call Ringing.

Interrelation Zones: None

## 105 Ring Off Time



<-- Program Status Area

<-- SSS=000~255


Def.=004=4 sec.

### Description:

Ring Off Time is the maximum time duration between ring bursts of an incoming call for the system to identify an abandoned incoming call.

Interrelation Zones: None

## 106 Flash Time for Key Phone & Overriding Flash Time for PSTN Line



<-- Program Status Area

<-- SSS=000~255

Def.=015=15x40=600 ms

### Description:

#### ■ Flash Time for Key Phone

Flash Time is a time specification of [FLASH] key on key telephone and allows the user to terminate an external call but still retain the same line for another outgoing call. The time must coincide with the termination time of the CO.

#### ■ Overriding Flash Time for PSTN Line ( [#]+[5]+[9] )

When the internal station is engaged with a CO line, any other incoming call through PSTN to the internal station on the same engaged CO line, the system can send a FLASH signal to the PSTN as soon as the internal station dials [#][5][9] to ask PSTN to switch the internal station between these two PSTN calls. The timing of the FLASH signal is programmed here.

- The function is provided by the PSTN itself; therefore, the user must apply for such function from your PSTN first.
- [The Time in **PROGRAM ZONE 106**] – [Flash signal Time of PSTN] ≥ 40ms.

### OPERATION EXAMPLE:

**Step 1.** Station is engaged with external party A on a CO line.

**Step 2.** Another external party B makes incoming call to the station through the same engaged CO line, the PSTN will send “Overriding Alert Tone” to the station.

**Step 3.** During the station hearing the “Overriding Alert Tone”, the station must puts the engaged CO line on hold first and then dials [#] + [5] + [9].

**Step 4.** The system will send out a FLASH signal which the timing is setup in **PROGRAM ZONE 106** to PSTN. As soon as PSTN receives the FLASH signal sent from the system will puts the external party A on hold and connect external party B to the station.


**Step 5.** Station can repeat the above Step 3 and Step 4 to talk to either the external party A or the external party B. If station hangs

## INITIALIZATION

up the call during the conversation will disconnected both external parties.

Interrelation Zones: None

### 107 Hold Recall Time




#### Description:

If the held call is not retrieved prior to the Hold Recall Time being reached, it will revert to the holding station.

- If the held call is still not answered after a pre-determined Hold Recall Timeout (see Program Zone 108) it will automatically transfer to the Attendant Console in the same station group as the holding station.


Interrelation Zone: Program Zone 108

### 108 Hold Recall Timeout



#### Description:


If the held call reverts to the holding station and is not answered before the setting time is reached, it will be transferred to an available console in **PROGRAM ZONE 400-GP-IP** which console's group is the same station group as the holding station in **PROGRAM ZONE 503-ST-1**.



- **Holding Time A:** The held call does not revert to the holding station.
- **Holding Time B:** The held call reverts back to the holding station.
- **Holding Time C:** The held call reverts back to the Attendant Console.

Interrelation Zone: Program Zone 107, 400-GP-IP and

## 109 Exclusive Hold Recall Time




<-- Program Status Area  
 <-- SSS=000~255  
 Def.=090=90 sec.

### Description:

If the exclusive held call is not retrieved prior to the setting time being reached it will revert to the holding station.

Interrelation Zone: Program Zone 110


## 110 Exclusive Hold Recall Timeout



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=030=30 sec.

### Description:


If the exclusive held call reverts to the exclusive holding station and is not answered before the setting time is reached, it will be transferred to an available console in **PROGRAM ZONE 400-GP-IP** which console's group is the same station group as the holding station in **PROGRAM ZONE 503-ST-1**.



- **Holding Time A:** The held call does not revert to the holding station.
- **Holding Time B:** The held call reverts to the holding station.
- **Holding Time C:** The held call reverts to the Attendant Console.

Interrelation Zone: Program Zone 109, 400-GP-IP and

## 111 SLT Dial Tone Timeout



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=015=15 sec.

### Description:

On lifting the handset of the SLT a dial tone will be followed by a busy tone if no digits have been dialed prior to the setting time being reached.

If the setting time exceeds 5 seconds, any of the following ON-HOOK operations from the key phone will have the same limit. If the setting time is **less than 5 seconds** the following operations will be restricted when the 5


## INITIALIZATION

seconds setting time is reached.

- Pressing [SPK] key without dialing.
- Pressing [FUNC] key without dialing.
- Accessing a CO line without dialing.
- Pressing [SPD] key without dialing.
- Pressing [\*] key without dialing.

Interrelation Zones: None

### 112 SLT Inter-Dialing Timeout




<-- Program Status Area  
<-- SSS=000~255  
Def.=035=35 sec.

#### Description:

If the dialing time between any two (2) digits is longer than the setting time the busy tone will be heard.

Interrelation Zones: None

### 113 Transfer Busy Recall Timeout




<-- Program Status Area  
<-- SSS=000~255  
Def.=030=30 sec.

#### Description:

If an incoming call is transferred to a busy station and is not answered prior to the setting time being reached, the call will be diverted to the transferring station.

Interrelation Zone: Program Zone 114

### 114 Transfer No Answer Recall Timeout



<-- Program Status Area  
<-- SSS=000~255  
Def.=030=30 sec.


#### Description:

Incoming call is transferred to a free station and not answered prior to the setting time being reached will be diverted to the transferring station.

Interrelation Zone: Program Zone 113

## INITIALIZATION

### 115 CFW No Answer Transfer Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=010=10 sec.

#### Description:

When calling a free station A which is programmed Call Forward No Answer to station B, if station A doesn't answer prior to the setting being reached, the call will be transferred to station B.

Interrelation Zone: Program Zone 113

### 116 DISA No Answer Transfer Timeout




<-- Program Status Area  
<-- SSS=000~255  
Def.=025=25 sec.

#### Description:

When DISA call to an internal free station is not answered prior to the setting time being reached the call will be transferred to the Attendant Console according to **PROGRAM ZONE 219**.

Interrelation Zones: Program Zones 218, 219, and

### 117 DISA No Dialing Transfer Timeout




<-- Program Status Area  
<-- SSS=000~255  
Def.=005=5 sec.

#### Description:

If DISA call is answered by the system and no digits are entered prior to the setting time being reached, the call will be transferred to the Attendant Console according to **PROGRAM ZONE 219**.

Interrelation Zones: Program Zones 219, 400 and

### 118 DISA Enable Delay Time 1



<-- Program Status Area  
<-- SSS=000~255  
Def.=000=0 sec.

#### Description:


If CO line is assigned in **PROGRAM ZONE 603-CO-2 = 0 or 1**, DISA incoming through such CO line will be answered by the system as soon as

## INITIALIZATION

the setting time is reached.

**Interrelation Zone: Program Zones 604-CO-2 and**

### 119 DISA Engaged Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=190=190 sec.

#### Description:

Determines the amount of time a DISA line can be used during External Call Forward (ECF) or when making another outgoing call. The engaged timing of 3-parties conference is also restricted by this parameter.

**Interrelation Zone: Program Zone 604-CO-3**

### 120 Auto Redial Waiting Time (On Hook)



<-- Program Status Area  
<-- SSS=000~255  
Def.=010=10 sec.

#### Description:


Once the auto-redial function is activated and the handset is not picked up

prior to the setting time being reached, the CO line will be automatically disconnected by the system. The auto-redial function will be placed into Auto Redial Pause Time status in **PROGRAM ZONE 121**.

This process (**PROGRAM ZONE 120 + 121**) is repeated for the number of times defined in **PROGRAM ZONE 223**, cancelled by the caller releasing the line manually or picking up the handset.

**Interrelation Zones: Program Zones 121 and 223**

### 121 Auto Redial Pause Time (On Hook)




<-- Program Status Area  
<-- SSS=000~255  
Def.=010=10 sec.

#### Description:


Determines the time between CO line disconnection and re-access during Auto-Redial function.

**Interrelation Zones: Program Zones 120 and 223**





## 122 Busy Reminder Interval Time




<-- Program Status Area  
 <-- SSS=000~255  
 Def.=020=20 sec.

### Description:

When an incoming call rings or to be transferred to a busy station a tone will be heard at intervals set in this parameter to remind the busy station. If the busy station is the 25 buttons key phone the reminder tone will be heard from the speaker, and from the handset if it is a SLT or 15 buttons key phone. **If SSS = 000, means the function will be disabled, too.**

Interrelation Zone: Program Zone 229

## 123 Incoming Hunt Ring Time



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=015=15 sec.


### Description:

When an incoming call rings to a free station the call will be transferred to the next available station in the same station group if the setting time is reached before the free station answers the call. If a busy station replaces a

free station the call will be transferred immediately to the next available station.

Interrelation Zones: Program Zones 604-CO-7(8)

## 124 Door Sensor Detection Ringing Time




<-- Program Status Area  
 <-- SSS=000~255  
 Def.=000=0 sec.

### Description:

Determines the ringing duration on the assigned stations in **PROGRAM ZONE 602** when the door sensor has been activated and detected by the system.

Interrelation Zone: Program Zone 303 and 602

## 125 Busy Tone On (I) Detection Time NOTE 3.



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=025=25x20=500 ms

## INITIALIZATION


### Description:

This parameter can only work during **ECF** or when making another outgoing call through DISA. The Tone Decoder of the system will detect “On” signal of the first Busy Tone sent from CO after the external party hangs up the call. If the time of Busy Tone “On” signal on CO loop is the same as the setting time, the system will recognize Busy Tone “On” signal.

**NOTE 3:** 1. The function is not available in AV-256.  
2. The function only can be worked with Voice

Interrelation Zones: Program Zones 126, 221 and 233

## 126 Busy Tone Off (I) Detection Time NOTE 3.



<-- Program Status Area  
<-- SSS=000~255  
Def.=025=25x20=500 ms


### Description:

This function is the same as **PROGRAM ZONE 125** but replaced “On” signal by the “Off” signal of the first Busy Tone.

**NOTE 4:** The complete Busy Tone (I) is only recognized by the system if the following parameters are effective.

Interrelation Zones: Program Zones 125, 221 and 233

## 127 Busy Tone On (II) Detection Time NOTE 3.




<-- Program Status Area  
<-- SSS=000~255  
Def.=012=12x20=240 ms

### Description:

The same as **PROGRAM ZONE 125** but for the second type of Busy Tone detection.

Interrelation Zones: Program Zones 128, 221 and 233

## 128 Busy Tone Off (II) Detection Time NOTE 3.



<-- Program Status Area  
<-- SSS=000~255  
Def.=012=12x20=240 ms

### Description:

The same as **PROGRAM ZONE 126** but for the second type of Busy Tone detection.


## INITIALIZATION

**NOTE 5:** Busy Tone (II) is only recognized if the following parameters are effective.

1. Busy Tone On (II) ----- Program Zone 127.
2. Busv Tone Off (II) ----- Program Zone 127.

Interrelation Zones: Programs Zone 127, 221 and 233

### 129 CO Delay Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=003=3x40=120 ms

#### Description:

When accessing a free CO line the system will delay the setting time duration to open the internal CO loop. All digits dialed during the setting delay time interval will be received by the system and will not be sent out until the setting time is reached.

Interrelation Zone: Program Zone 216

### 130 CO Access Delay Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=000=0 sec.

#### Description:

A free CO line can not be retrieved after it is released until the setting time is reached.

Interrelation Zones: None

### 131 Door Ringing Delay Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=000=0 sec.

#### Description:

When the Door Sensor is activated the assigned stations in **PROGRAM ZONE 602** will not be ringing until the setting time is reached.

Interrelation Zone: Program Zone 602

## 132 Metering Pulse Delay Time



&lt;-- Program Status Area

&lt;-- SSS=000~255

Def.=000=0 sec.


### Description:

This parameter allows the system to remain on the detection of the metering pulse during the setting time after the CO line is disconnected.

**NOTE 6:** This function is only available for AV-64 and

**Interrelation Zone: Program Zone 251**

## 133 DISA Console Busy Transferring Time



&lt;-- Program Status Area

&lt;-- SSS=000~255

Def.=015=15 sec.


### Description:

If the DISA call is transferred to the consoles which are all busy the system will recheck the consoles and sound a reminder tone if they are still busy. During the rechecking the call will be transferred to any console found to be

free or the line will then be released if all consoles are still busy after three rechecks.

**Interrelation Zone: Program Zone 218, 219 and 400**

## 134 Incoming Delay Time



&lt;-- Program Status Area

&lt;-- SSS=000~255

Def.=000=0 sec.

### Description:


Once the line is released the user cannot access the same CO line for outgoing calls until after the setting time is reached.

**NOTE 7:** This function only available for the Australian

**Interrelation Zones: None**

## 135 The 2nd DSS Page Remaining Time or SLT MSG Wait Silence Time

### ■ The 2nd DSS Page Remaining Time



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=006=6 \*5=30Sec


#### Description:

Once the DSS Key Page is turned to the 2nd page by pressing DSS Key with FUNC CODE=80 in **PROGRAM ZONE 500-GP-IP**, it will not turn to the 1st DSS Key Page automatically until the setting time is reached.

Interrelation Zones: Program Zones 500-GP-IP,

### ■ SLT Message Wait Silence Time (Only available for Australia)

Refer to Example 1 in PROGRAM ZONE 136



<-- Program Status Area  
 <-- SSS=007~255  
 Def.=060=300 sec.=5 min.


#### Description:

To determine SLT silence interval between 2 ringing when leaving MSG Waiting to No Answer SLT station. **The setting value must be ≥ 007.**

Interrelation Zones: Program Zone 212

## 136 SOS Enable Delay Time or SLT MSG Wait Ringing Time

### ■ SOS Enable Delay Time




<-- Program Status Area  
 <-- SSS=000~255  
 Def.=000=6 sec.

#### Description:

SOS function will not be enabled until the setting time is reached after the SOS sensor is activated.

Interrelation Zones: Program Zones 303 and 301-02

### ■ SLT MSG Wait Ringing Time (Only available for Australia)



<-- Program Status Area  
 <-- SSS=000~255  
 Def.=006=30 sec.

## INITIALIZATION


### Description:

To determine the amount of the SLT ringing interval after a free SLT station has been left the MSG Waiting.

**Interrelation Zones: Program Zone 212**

### Example 1: PROGRAM ZONE 135=060 and PROGRAM ZONE 136=006

- Step 1. Station makes intercom to call a free SLT station.
- Step 2. Station presses [MSG] function key (if it is key phone) or digit [6] (if it is SLT) to leave message waiting to free SLT station during hearing ring back tone.
- Step 3. Free SLT station will stop ringing immediately for 5 minutes (PROGRAM ZONE 135=060=300sec.=5 min.) and then have 30 seconds ringing (PROGRAM ZONE 136=006=30sec.), and then 5 minutes silence + 30 seconds ringing. Please refer to the following diagram:



## 137 Metering Pulse Detection Starting Time

**Aristel** ---

137 Meter range1  
Time=008 (\*10ms)

AV SERIES

<-- Program Status Area

<-- SSS=000~255

Def.=008=80 ms.

### Description:

(The function is only available in AV-38 and AV-64)

The Metering pulse only can be detected by the system within “Metering Pulse Detection Starting Time” and “Metering Pulse Detection Ending Time”.

**Interrelation Zones: Program Zones 132, 138 and 251**

## 138 Metering Pulse Detection Ending Time

**Aristel** ---

138 Meter range2  
Time=030 (\*10ms)

AV SERIES

<-- Program Status Area

<-- SSS=000~255

Def.=030=300 ms.

### Description:

(The function is only available in AV-38 and AV-64)


The Metering pulse only can be detected by the system within “Metering Pulse Detection Starting Time” and “Metering Pulse Detection Ending Time”.

## INITIALIZATION

Time”.

Interrelation Zones: Program Zones 132, 137 and 251

### 139 ACD Enable Time




<-- Program Status Area  
<-- SSS=000~255  
Def.=015=15 sec.

#### Description:

Incoming call rings to the assigned stations in **PROGRAM ZONE 600 (601)** when they are all busy, the call will be answered by the system once the setting time is reached and be put into the holding queue whilst the caller will hear ACD Reminding Message and MOH. As soon as any one of the assigned station is free the call will be transferred to that free station. The Holding Queue is proceeded **First-In** and **First-Out**.

Interrelation Zones: Program Zones 402-NN-IP=16(17),

### 140 DISA Enable Delay Time 2



<-- Program Status Area  
<-- SSS=000~255  
Def.=000=000 sec.


#### Description:

(The function is only available in AV-64 and AV-256)

If CO line is assigned in **PROGRAM ZONE 603-CO-2 = 2 or 3**, DISA incoming through such CO line will be answered by the system as soon as the setting time is reached.

Interrelation Zone: Program Zones 604-CO-2 and

### 141 DISA Enable Delay Time 3



<-- Program Status Area  
<-- SSS=000~255  
Def.=000=000 sec.

#### Description:

(The function is only available in AV-64 and AV-256)


If CO line is assigned in **PROGRAM ZONE 603-CO-2 = 4 or 5**, DISA incoming through such CO line will be answered by the system as soon as

## INITIALIZATION

the setting time is reached.

Interrelation Zone: Program Zones 604-CO-2 and

### 142 DISA Enable Delay Time 4



<-- Program Status Area  
<-- SSS=000~255  
Def.=000=000 sec.


#### Description:

(The function is only available in AV-64 and AV-256)

If CO line is assigned in **PROGRAM ZONE 603-CO-2 = 6** or 7, DISA incoming through such CO line will be answered by the system as soon as the setting time is reached.

Interrelation Zone: Program Zones 604-CO-2 and

### 143 Door Call Ringing Time



<-- Program Status Area  
<-- SSS=000~255  
Def.=020=020 sec.


#### Description:

(The function is only available in AV-38 and AV-256)

The assigned stations in **PROGRAM ZONE 602** will be ringing for the period of setting time as soon as the Door Phone Button is pushed once.

Interrelation Zone: Program Zones 602

### 144 System Wide FWD Time



<-- Program Status Area  
<-- SSS=000~255  
Def.=020=020 sec.

#### Description:

DID incoming call or DISA incoming call or Intercom call rings to the internal free station which **PROGRAM ZONE 504-ST-8=1** and without answered, the call will be forwarded to the first assigned station in **PROGRAM ZONE 400-05-IP** as soon as the setting time is reached.



## INITIALIZATION

- The function is not available in AV-38/AV-64/AV-256.


Interrelation Zone: Program Zones 242, 400-05

---

**145 ~ 199 Reserved for Future Use**

## ■ System Function Parameter (Zone 200 ~ 299)

### 200 PABX (Centrex) Outgoing Code



&lt;-- Program Status Area

&lt;-- S=0~9


Def.=9

#### Description:

If the system is installed behind a Host PABX an Access Code (0-9) is needed be assigned to access Central Office Lines from the Host PABX. This function is available when **PROGRAM ZONE 604-CO-1=1=PABX** and is used for Redial and Toll Restriction functions (this means the system will not detect the first dialing digit after the CO Line is accessed).

Interrelation Zone: Program Zone 604-CO-1=1

### 201 Operator Code



&lt;-- Program Status Area

&lt;-- S=0~9


Def.=0

#### Description:

It is one touch code for station to call operator urgently.

Interrelation Zone: Program Zone 400

### 202 Dial \_9 CO Code



&lt;--Program Status Area

&lt;--S=0~9

Def.=9

#### Description:


It is one touch code for a station to urgently access a free CO line from the system.

**NOTE 8:** Dial \_9 CO Code cannot be the same as

## INITIALIZATION

Interrelation Zones: Program Zones 503-ST-3

### 203 Toll Code




<-- Program Status Area  
<-- S=0~9  
Def.=0

#### Description:

The stating code allocated in the first digit of the outgoing dialed numbers to let the system recognize that the outgoing call is the long distance call.

Interrelation Zones: Program Zones 405, 408 and 409

### 204 12/24 Hour Clock




<-- Program Status Area  
<-- S=0~1  
Def.=1

#### Description:

0 = 12 hour format 1 = 24 hour format (Military)

Interrelation Zones: Program Zones 304, 305, 306 and

### 205 Station Number Digit Length



<-- Program Status Area  
<-- S=2~4  
Def.=2


#### Description:

Defines the length of a station number assigned in **PROGRAM ZONE 502-CSN-1**.

2 = 2 digits 3 = 3 digits 4 = 4 digits

Interrelation Zone: Program Zone 502-CSN-1

## 206 Digit Length for Local Call



&lt;-- Program Status Area

&lt;-- S=0~9

Def.=0

### Description:

Defines the length of a local telephone number restricted in **PROGRAM ZONE 203** and **405**.

0 = Infinite    1 = 1 digit    2 = 2 digits    ..... 9 = 9 digits


**Interrelation Zones:**    Program Zones 307-03 and

phone station when it is intercom-called by another internal station.  
The caller can press [\*] to change the calling type during the calling.

0 = Voice Signaling    1 = Ring Signaling

**Interrelation Zones:**    None

## 208 Intercom Dial Tone Signaling



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=0


### Description:

Defines the Internal Dial Tone signal when station's handset is lifted (Key Phone or SLT) or **[SPK]** is pressed (Only for Key Phone).

0 = Steady Tone    1 = Interrupted Tone

**Interrelation Zones:**    None

## 207 Intercom Calling Type (for KP)



&lt;-- Program Status Area


&lt;-- S=0~1

Def.=1

### Description:

Defines the initial calling signal on the speaker of an internal key

## 209 Intercom One Digit Dialing Capability



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=0


### Description:

Determines whether the user can call intercom by dialing the representative single digit of the called station defined in PROGRAM ZONE 401.

0 = Disabled      1 = Enabled

Interrelation Zones: Program Zone 401

## 210 Intercom Hunting



&lt;-- Program Status Area

&lt;-- S=0~3

Def.=0

### Description:


Allows an internal caller to press digit [4] to search for the next free station if the called station is busy or does not answer. The next free station must be in the same station group as the called station in PROGRAM ZONE 503-ST-1.

0 = Disable Intercom Hunting

1 = Enable Intercom Hunting

Interrelation Zones: Program Zone 503-ST-1

## 211 Wake Up Call Signaling



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=1

### Description:


0 = Use Voice Message to perform Wake Up Call service.

1 = Use background music to perform Wake Up Call service.

Interrelation Zones: Individual Alarm Clock in System

## INITIALIZATION

### 212 Message Wait Auto Ringing



<-- Program Status Area

<-- S=0~2

Def.=1

#### Description:

(The function is not available for free Key Phone)

0 = Disable Message Wait Auto Ringing

1 = Enable Message Wait Auto Ringing in Ringing Mode

2 = Enable Message Wait Auto Ringing in Voice Mode

#### OPERATION EXAMPLE:

**Step 1.** Station A calls free Station B which is SLT.

**Step 2.** Station B does not answer.

**Step 3.** Station B stops ringing once Station A leaves message to Station B during ringing.


**Step 4.** Station B will ring for 30 seconds each 5 minutes.

**Step 5.** Station A will be rung as soon as Station B answers the message ringing, then Stations A and B can talk to each other.

**NOTE 9:** If Station A leaves the message to busy Station B which is either SLT or Key Phone,

Interrelation Zones: Program Zone 402

### 213 Make/Break Ratio



<-- Program Status Area

<-- S=0~1

Def.=0


#### Description

Sets the Make to Break Ratio for Dial Pulse signal when CO is programmed for Pulse signal output in **PROGRAM ZONE 604-CO-1=0**.

0 = 33/66      1 = 40/60

Interrelation Zone: Program Zone 604-CO-1=0

### 214 Automatic CO Search



<-- Program Status Area

<-- S=0~1

Def.=1

## INITIALIZATION


### Description:

Allows the system to select a free CO line automatically during **Speed Dial, Auto Redial and Redial**.

0 = Disable            1= Enable

Interrelation Zones:	None
----------------------	------

## 215    Dial \_9 Capability



<-- Program Status Area  
<-- S=0~2  
Def.=1


### Description:

Allows the user to access a free CO line by pressing a specified code assigned in **PROGRAM ZONE 202**.

- 0 =     Disable.**
- 1 =     Enable. Co line is accessed by the normal way from the free line in PROGRAM ZONE 603.**
- 2 =     Enable. CO line is accessed by the circular way from the free line in PROGRAM ZONE 603.**

Interrelation Zones:	Program Zones 202, 503-ST-3
----------------------	-----------------------------

## 216    CO Delay Capability/Paging Tone of 15 Keys KP



<-- Program Status Area  
<-- S=0~1  
Def.=0

### Description:

#### ■ CO Delay Capability

The system will delay a setting time after CO line is accessed so as to avoid losing the first dialing digit detected by the CO when quick dialing is used.

0 = Disable            1 = Enable

#### ■ Paging Tone of 15 Keys KP


**(The function is only available for AV-38, AV-64 and AV-256)**

Allows the user to select the different paging tone on 15 buttons key telephone when it is paged by another internal station.

0 = Ding-Dong            1 = One second tone

Interrelation Zone:	Program Zone 129
---------------------	------------------

## 217 Mute CO Capability



<-- Program Status Area

<-- S=0~1

Def.=0

### Description:


Provides protection if an external DTMF dialer is used on the key station handset.

0 = Disable

1 = Enable. Key station handset will be muted until the 3rd digit is dialed.

Interrelation Zones: None

## 218 DISA Recall Capability



<-- Program Status Area

<-- S=0~3

Def.=0

### Description:

Allows DISA caller to be transferred to the Attendant Console if the called station is busy or does not answer.

0 = Disable.

1 = Enable when No Answer. The call will be transferred to the console(s) according to **PROGRAM ZONE 219** as soon as the setting time in **PROGRAM ZONE 116** is reached.

2 = Enable when busy or a non existent station number. The call will be transferred to the console(s) according to **PROGRAM ZONE 219** immediately when the called station is busy or if dialing a non existent station number.

3 = Enable when no answer, busy or non existent station number. The same operating procedures as "1" or "2".

After the call is the first time transferred to the console(s) and the consoles are all busy or do not answer the call, the call will be put into the holding queue and the busy consoles will hear one second Remind Tone. The system will make the 2nd recheck to the consoles as soon as the setting time in **PROGRAM ZONE 133** (for consoles are all busy) or **PROGRAM ZONE 116** (for consoles do not answer the call) is the first time reached. If the call still does not be answered during the 2nd time recheck, the system will make the 3rd recheck to the consoles as soon as the setting time in **PROGRAM ZONE 133** (for consoles are all busy) or **PROGRAM ZONE 116** (for consoles do not answer the call) is




## INITIALIZATION

the second time reached. If the call still does not be answered during the 3rd time recheck, the system will disconnect the call immediately. The total maximum recheck times will be three (3) times.

**Interrelation Zones: Program Zones 116, 117, 219**

## 219 DISA Transfer Group Capability



<-- Program Status Area  
<-- S=0~5  
Def.=0

### Description:

Determines where the DISA call is transferred to if the called station does not answer.

- 0 = Transferred to the first available Console in the same Console Group as the called station group number.
- 1 = Transferred to the first available Console in the same Console Group as the CO group number of the DISA line in **PROGRAM ZONE 603** (when **PROGRAM ZONE 222=1**) or in **PROGRAM ZONE 608** (when **PROGRAM ZONE 222=2**).

- 2 = Transferred to all Consoles in the same Console Group as the called station group number.
- 3 = Transferred to all Consoles in the same Console Group as the CO group number of the DISA line in **PROGRAM ZONE 603** (when **PROGRAM ZONE 222=1**) or in **PROGRAM ZONE 608** (when **PROGRAM ZONE 222=2**).
- 4 = Transferred to the consoles according to the following 3 conditions:

**DAY TIME** : Transfer to the consoles in the console's group which is the same group number as Station Group Number of the called station in **PROGRAM ZONE 503-ST-1**. The consoles will ring.

**MIDDAY TIME** : Transfer to the consoles in the console's group which is the same group number as Station Group Number of the called station in **PROGRAM ZONE 503-ST-1**. The consoles will not ring but have an Alert Tone to be heard from the speaker.

**NIGHT TIME** : Same as MIDDAY TIME.

- 5 = Transferred to the consoles according to the following 3 conditions:

## INITIALIZATION


**DAY TIME** : Transfer to the consoles in the console's group which is the same group number as Station Group Number of the called station in **PROGRAM ZONE 503-ST-1**. The consoles will ring.

**MIDDAY TIME** : Transfer to the consoles in **PROGRAM ZONE 400-04**. The consoles will not ring but have an Alert Tone to be heard from the speaker.

**NIGHT TIME** : Transfer to the consoles in **PROGRAM ZONE 400-06**. The consoles will not ring but have an Alert Tone to be heard from the speaker.

**Interrelation Zones: Program Zones 116, 117, 133, 218, 222, 308, 400-04-IP, 400-06-IP, 503-ST-1, 604-CO-3**

## 220 Fax Monitoring Capability




<-- **Program Status Area**  
<-- **S=0~1**  
**Def.=1**

### Description:

0 = Disable      1 = Enable

**Interrelation Zones: None**

## 221 Busy Tone Detection/Hold Reminder Capability



<-- **Program Status Area**  
<-- **S=0~3**  
**Def.=3**

### Description:

**(The function is not available for AV-256)**


- 0 = Disable Busy Tone Detection, Holding Reminder Message and Holding Music when DISA call is transferred.
- 1 = Enable Busy Tone Detection, Disable Holding Reminder Message and Holding Music when DISA call is transferred.
- 2 = Disable Busy Tone Detection, Enable Holding Reminder Message and Holding Music when DISA call is transferred.
- 3 = Enable Busy Tone detection, Holding Reminder Message and Holding Music when DISA call is transferred.

## INITIALIZATION

**NOTE 10:** Busy Tone Detection can only operate during External call Forward (ECF) or when accessing CO line for another

**Interrelation Zones:** Program Zones 125, 126, 127,

### 222 DSS Key for Different CO Group



<-- Program Status Area  
<-- S=0~2  
Def.=1

#### Description:

Allows the internal station to be restricted by **PPROGRAM ZONE 603** when pressing DSS CO line for outgoing call or answering an incoming call according to **PROGRAM ZONE 503-ST-4** and **PROGRAM ZONE 608**.

0 = Disable.


1 = The station is restricted by **PRPROGRAM ZONE 603** if pressing DSS CO line key for outgoing call.

2 = The station can answer or pick up the incoming line according to **PROGRAM ZONE 503-ST-4** and **PROGRAM ZONE 608**, even if

it is restricted by **PROGRAM ZONE 603**.

**Interrelation Zones:** Program Zones 503-ST-4, 603

### 223 Auto-Redial Times




<-- Program Status Area  
<-- S=00~99  
Def.=20

#### Description:

Determines the redial times (total cycles of Auto Redial Pause Time + Auto Redial Waiting Time) when Auto Redial is activated.

**Interrelation Zones:** Program Zones 120 and 121

### 224 Limit Call Pattern



<-- Program Status Area  
<-- S=0~8  
Def.=2

## INITIALIZATION

### Description:

Determines the limiting status before the time in **PROGRAM ZONE 507-ST-2** is reached.


- 0 = Continuous warning tone after timeout<sup>NOTE 11</sup>
- 1 = A one (1) second warning tone for each Call Limit Duration<sup>NOTE 11</sup>
- 2 = At ten (10) seconds before timeout, a one (1) second warning tone will sound. At five (5) seconds before timeout, a continuous warning tone can be heard by the internal key station party (If SLT station then both internal and external parties can hear). The line is released after timeout. **NOTE 11**
- 3 = At ten (10) seconds before timeout, a one (1) second warning tone will sound. At five (5) seconds before timeout, a continuous warning tone will be heard by both parties. After timeout, the line is released. **NOTE 11**
- 4 = Reserved.
- 5 = The same as 0 for incoming and outgoing calls.
- 6 = The same as 1 for incoming and outgoing calls.
- 7 = The same as 2 for incoming and outgoing calls.
- 8 = The same as 3 for incoming and outgoing calls.
- 9 = Reserved.

**NOTE 11:** 0, 1, 2 and 3 are for outgoing calls only

Interrelation Zone:

Program Zone 507-ST-3

## 225 Speed Dial Distribution



<-- Program Status Area

<-- S=0~1

Def.=0

### Description:

Defines the quantities of System Speed Dial and Individual Speed Dial sets. The following tables are for the total sets for System Speed Dial plus Individual Speed Dial before or after **Name Speed Dial** function in **PROGRAM ZONE 227** is enabled. Refer to **PROGRAM ZONE 509** for Individual Speed Block and **PROGRAM ZONE 404** for System Speed Dial Code assignment.

### When PROGRAM ZONE 227 = 0 = Disable Name Speed Dialing

Setting Value	System Speed Dial Sets		Individual Speed Dial Sets	
	AV-8/NAV-8/ AV-12/38	AV-64/256	AV-8/NAV-8/ AV-12/38	AV-64/256
0	100 (100 ~ 199)	100 (100 ~ 199)	600	1100
1	200 (100 ~ 299)	200 (100 ~ 299)	500	1000
2	300 (100 ~ 399)	300 (100 ~ 399)	400	900
3	400 (100 ~ 499)	400 (100 ~ 499)	300	800
4	500 (100 ~ 599)	500 (100 ~ 599)	200	700

## INITIALIZATION


<b>5</b>	600 (100 ~ 699)	600 (100 ~ 699)	100	600
<b>6</b>		700 (100 ~ 799)		500
<b>7</b>		800 (100 ~ 899)		400
<b>8 ~ 9</b>		900 (100 ~ 999)		300

## When PROGRAM ZONE 227 = 1 = Enable Name Speed Dialing

Setting Value	System Speed Dial Sets		Individual Speed Dial Sets	
	AV-8/NAV-8/ AV-12/38	AV-64/256	AV-8/NAV-8/ AV-12/38	AV-64/256
0	100 (100 ~ 199)	100 (100 ~ 199)	250	500
1	200 (100 ~ 299)	200 (100 ~ 299)	150	400
2	300 (100 ~ 399)	300 (100 ~ 399)	50	300
3	300 (100 ~ 399)	400 (100 ~ 499)	50	200
4 ~ 9	300 (100 ~ 399)	500 (100 ~ 599)	50	100

<b>Interrelation Zones:</b>	<b>Program Zones 227, 404</b>
-----------------------------	-------------------------------

## 226 Speed Dial Unrestricted Range



```
<-- Program Status Area
<-- AAA=SPD CodeNOTE 12
   BBB=SPD CodeNOTE 12
   Def=AAA→BBB
      =000→000
```

### Description:

Allows System Speed Dial Numbers to be exempt from Toll Restriction.

### EXAMPLE:


1. Entering AAA → BBB (where AAA → BBB are variables, eg 100 ~ 255), SPD Codes from 100 ~ 255 can override Toll.
2. Entering AAA → BBB (where AAA → BBB are variables, eg 234 ~ 456), SPD Codes from 234 ~ 456 can override Toll.
3. Entering the first digit of AAA as 0, All SPD Codes will be Toll Restricted.

**NOTE 12:**

<b>AV-8/NAV-8</b>	-----> AAA = 000 → 699 BBB = 000 → 699
<b>AV-12/38</b>	-----> AAA = 000 → 699 BBB = 000 → 699

<b>Interrelation Zones:</b>	<b>Program Zones 404 and 405</b>
-----------------------------	----------------------------------

## 227 Name Speed Dial Capability



```
<-- Program Status Area
<-- S=0~1
    Def.=0
```

**Description:**

Allows the user to enter a name to replace the speed dial code for


## INITIALIZATION

System or Individual Speed Dial, or entering the prefix of a name to search for the speed dial number.

0 = Disable      1 = Enable

Interrelation Zones:    Program Zones 404, 500 - FN=74,  
502, 604 and System

### 228 SMDR Masked Capability



<-- Program Status Area  
<-- S=0~9  
Def.=0


#### Description:

Determines how many digits of the dialed telephone number can be printed through SMDR.

0 = Print out all digits of the dialed number.  
1 = Print out only the first digit of the dialed number.  
9 = Print out the first 9 digits of the dialed number.

Interrelation Zone: Program Zone 307

### 229 Busy Reminder Capability



<-- Program Status Area  
<-- S=0~1  
Def.=1


#### Description:

If the function is enabled, the busy internal station can hear Busy Reminder Tone from the handset of SLT or 15 buttons Key Phone if another call is transferred in.

0 = Disable      1 = Enable

Interrelation Zone: Program Zone 122

### 230 Link Monitor Capability



<-- Program Status Area  
<-- S=0~1  
Def.=0

#### Description:

## INITIALIZATION


Allows the system to maintain its cross-links when an external line is disconnected abnormally.

0 = Disable

1 = Enable. If the problem is caused by the system itself, the user will experience a short interruption while the connection is restored automatically. If the problem is caused by the external CO or a wiring connection, the link will not be restored.

Interrelation Zone: None

### 231 Volume – Initial Setting




<-- Program Status Area  
<-- S=1~8  
Def.=3

#### Description:

Defines the initial volume level for Speaker, Ringing and Handset Tones when Key Phone is reset. A total of eight (8) levels can be assigned.

Interrelation Zones: None

### 232 Speed Dial Pause Times



<-- Program Status Area  
<-- SS=00~99  
Def.=09

#### Description:

Defines one Pause (p) in Speed Dial Number

#### EXAMPLE:


Step 1. Program Zone 100 = 020 = 20 x 40 = 800ms.

Step 2. Program Zone 232 = 07 = 7 x 800 = 5600ms = 5.6 sec.

Step 3. Speed Dial Number is "002P886PP2P9993380", the time for one "p" here is (5.6 + 0.8) = 6.4 sec.

Interrelation Zones: Program Zones 100 and 404

### 233 Busy Tone Detection Times<sup>NOTE 3</sup>



<-- Program Status Area  
<-- SS=00~99  
Def.=06


## INITIALIZATION

### Description:

Defines how many cycles of Busy Tone ON + Busy Tone OFF detected by the system can be assumed as a real Busy Tone sent from CO after the external party hangs up the call.

Interrelation Zones: Program Zones 125, 126, 127,

## 234 CO Auto-Transfer Capability



<-- Program Status Area  
<-- S=0~1  
Def.=1

### Description:


Allows the internal party to transfer the external call without pressing **[TRF/FL]** key, but instead pressing either **[PAGE]** or **[DSS Station]** keys. Pressing **[PAGE]** key will put the call on hold automatically and transfer as soon the internal party hangs up after the internal paged party answers the call. Pressing **[DSS Station]** key will put the call on hold automatically and it will be camped on to the called station as soon as the internal party hangs up the handset.

0 = Disable      1 = Enable

**Caution !** If the setting value = 1 will increase the system's working loading.

Interrelation Zones: None

## 235 System Programming Password Protection



<-- Program Status Area  
<-- S=0~1  
Def.=0


### Description:

Provides protection for the system to deny access to the system programming by any internal key station using the Engineering Programming Password except the key station located in the first station port in the system; however, any key station still can use the Programming Password in PROGRAM ZONE 301-01 to enter the system programming.

0 = Disable      1 = Enable

Interrelation Zone: Program Zone 303-01 and



**236 Dial Tone Detection Times**<sub>NOTE 3</sub>

&lt;-- Program Status Area

&lt;-- SS=00~99

Def.=06

**Description:**

Defines how many Special Dial Tones sent from Central Office after an external party hangs up the call and detected by the system, can be admitted as a requirement for the system to disconnect the CO line. (This function only exists in AV-16H/24/38)

Interrelation Zones: None

**Description:**

A very important function for SLT, especially when SLT is Pulse Dialing.


0 = Disable. Pulse dialing SLT cannot use some station functions which the operation digit is with [#] or [\*]. Digit [7] and [8] can be the first digit of the station number.

1 = Enable. Digit [#] and [\*] will be replaced by digit [7] and [8] when SLT is pulse dialing. The first digit of the station number cannot be [7] and [8].

2 = Digits [#] will be replaced by Digits [7]. Digit [\*] will be replaced by [8]. One FLASH Pulse will be replaced by digit [2].

3 = Same as above 2, but Account Code will be replaced by digit [5].

4.= Account Code will be replaced by digit [5].

**237 SLT Pulse Dialing Operation Code with  
[ # ]/[ \* ]**


&lt;-- Program Status Area

&lt;-- S=0~4

Def.=0

Interrelation Zones: Program Zone 403,

## 238 DISA Single Digit Dialing Capability



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=0


### Description:

Allows DISA caller to use a representative digit (1~5 and 7~8) to call internal stations assigned in **PROGRAM ZONE 607**. It is different from **PROGRAM ZONE 401**. Dialing [6] + [Station Number] is for calling specific station direct.

0 = Disable                      1 = Enable .

Interrelation Zone:      Program Zone 607

## 239 Do Not Disturb Capability



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=0

### Description:


Allows the user to disable “Do Not Disturb” function from the system even if the Function Key is assigned for “DND”.

0 = Disable. System has Do Not Disturb function.

1 = Enable. System does not have Do Not Disturb function.

Interrelation Zones:      System Administrator's

## 240 Auto-Accessing CO Line Capability



&lt;-- Program Status Area

&lt;-- S=0~1

Def.=0

### Description:


Allows the user to access a free CO line automatically by lifting up handset after **Hot Line Function** is enabled in **Site Administrator's Manual**.

0 = Disable. Can access CO line automatically by lifting the handset.

1 = Enable. Cannot access CO line automatically by lifting handset.

Interrelation Zone:      System Administrator's

## 241 Direct Intercom Dialing & FAC Uninhibited by Call Limit Duration Capability



<-- Program Status Area  
<-- S=0~3  
Def.=0

### Description:

Allows an internal party to call intercom by dialing station number direct without lifting handset or pressing [SPK] key. This function must be used carefully with **PROGRAM ZONE 209** and **238** which are used for single digit Dialing Capability.

**It is recommended that "Direct Dial" function to be disabled if PROGRAM ZONE 209 is enabled.**

0 = Disable Direct Intercom Dialing.


1 = Enable Direct Intercom Dialing.

2 = Disable Direct Intercom Dialing, and the call made by Forced Account Code will not be inhibited by Limit Call Duration.

3 = Enable Direct Intercom Dialing, and the call made by Forced Account Code will not be inhibited by Limit Call Duration.

**Interrelation Zone: Program Zone 209, 403 and  
507-ST-3**

## 242 Exclusive Hold & System Wide CFW Capability



<-- Program Status Area  
<-- S=0~3  
Def.=1

### Description:

#### A. Exclusive Hold Capability

Allows the user to select Exclusive Hold function.

#### B. System Wide CFW (The function is only available in AV-38/AV-64/AV-256)

System Wide CFW function has 2 following conditions:

##### ■ The called station is FREE:

**DISA** incoming call (Auto Attendant) or **DID** incoming call (ISDN DID) or **INTERCOM** call rings to an internal FREE station which **PROGRAM ZONE 504-ST-8=1** and without answered during the setting time in **PROGRAM ZONE 144** the call will be transferred to the first free assigned Station in **PROGRAM ZONE 400-05**.

##### ■ The called station is BUSY:

**DISA** incoming call (Auto Attendant) or **DID** incoming call

## INITIALIZATION

(ISDN DID) rings to an internal BUSY station which **PROGRAM ZONE 504-ST-8=1** and the called busy station has heard as twice as Busy Reminding Tone by the setting time in **PROGRAM ZONE 122** the call will be transferred to the first free assigned Station in **PROGRAM ZONE 400-05**.

0 = Disable XHold.

1 = Enable XHold.

2 = Disable XHold and System Wide CFW

3 = Enable XHold and System Wide CFW


Interrelation Zones: Program Zone 122, 144, 400-05,  
504-ST-8 and System

**NOTE 13:** SOS function will only operate with all of the following:

1. The user must assign one sensor for SOS function in Program Zone 303.
2. The user must record SOS message to voice sub-channel in Program Zone 402.
3. The user must assign SOS outgoing

Interrelation Zones: Program Zones 122, 144, 303,  
400-05-IP, 402, 404, 504-ST-8

### 243 SOS Outgoing-Playing Times



<-- Program Status Area

<-- SS=00~99


Def.=00

#### Description:

Defines how many times of the SOS Voice Messages can be repeated on the outgoing line when SOS function is activated.

**(This function is not available for AV-64/AV-256)**

### 244 Door Phone Sensor Capability



<-- Program Status Area

<-- S=0~2

Def.=0

#### Description:


As soon as either Door Sensor is activated or Door Phone button is pushed, the internal assigned stations in **PROGRAM ZONE 602** will be ringing according to the following service schedule:

## INITIALIZATION

- 0 = Both Day and Night enable
- 1 = Day disable, Night enable
- 2 = Day enable, Night disable

Interrelation Zones: Program Zones 124, 131, 249,

### 245 SLT & Voice Mail Message Waiting Function Capability



<-- Program Status Area  
<-- S=0~2  
Def.=0


#### Description:

Allows an internal SLT station or Voice Mail to leave messages to other internal parties by pressing the specific digit during a call.

- 0 = Disable
- 1 = Enable, SLT can leave message to another internal station by pressing digit **[6]**.
- 2 = Enable, Voice Mail can send the following codes to the system:  
pre-digit **[8]+[1]+[EXT NO]** to leave MSG and turn on the MSG lamp.  
pre-digit **[8]+[2]+[EXT NO]** to cancel MSG and turn off the MSG lamp.

Interrelation Zones: Program Zone 502-PORT-2,  
504-ST-3 and System

### 246 Voice Recording Copy Capability



<-- Program Status Area  
<-- S=0~3  
Def.=1

#### Description:


Allows the system to copy the same voice messages, which the user is recording to the voice channel, into another voice channel at the same time.

- 0 = All consoles in PROGRAM ZONE 400 can carry out VSU record/Play but without Copy function.**
- 1 = All consoles in **PROGRAM ZONE 400** can carry out VSU Record/Play with Copy function.
- 2 = Only consoles in **PROGRAM ZONE 400-08-01** can carry out VSU Record/Play but without Copy function.
- 3 = Only consoles in **PROGRAM ZONE 400-08-01** can carry out VSU Record/Play with Copy function.

## INITIALIZATION

Interrelation Zones: Program Zones 400, 402 and  
System Administrator's

### 247 Background Music For CO Incoming Ringing Signal Capability



<-- Program Status Area  
<-- S=0~1  
Def.=0


#### Description:

Replacing CO incoming ringing signal by background music (BGM) .

0 = Disable      1 = Enable

Interrelation Zones: Program Zones 600 and 601

### 248 Call Forward Function Capability



<-- Program Status Area  
<-- S=0~1  
Def.=1


#### Description:

Allows the user to disable/enable Call Forward function.

0 = Disable      1 = Enable

Interrelation Zone: System Administrator's

### 249 Ringing Signal For Door Phone Call



<-- Program Status Area  
<-- S=0~2  
Def.=0

#### Description:

Allows the user to select the internal ringing signal when door phone calls.

0 = The original door alarm.

1 = Background music.

2 = Incoming ringing signal.

Interrelation Zones: Program Zones 124, 131, 244

## 250 Capability Of Console Entering System SPD/Name SPD/Alarm

**Aristel** ---

250 Ind. Console  
CAP.=S (0:D 1:E)

**AV**

&lt;-- Program Status Area

&lt;-- S=0~1

Def.=1

### Description:

Determines whether the console can assign the System Speed Dial, Name Speed Dial and System Alarm by individual Station Programming.

0 = Disable      1 = Enable

Interrelation Zone:      System Administrator's

## 251 Metering Detection Capability or RS232 Modem Capability (Only for AV-38/AV-64/AV-256 equipped with EH-64)

**Aristel** ---

251 Metering  
CAP.=S (0:D 1:E)

**AV**

&lt;-- Program Status Area

&lt;-- S=0~4

Def.=0

### Description:

Allows the system to detect metering Pulse which is a counting signal for telephone call charge sent from CO.

0 = Disable.

1 = Detection 12 KHz Metering Pulse signal.

2 = Detection 16 KHz Metering Pulse signal.

3 = Detection 12 KHz Metering Pulse signal and Enable Hotel Function (EH64).

4 = Detection 16 KHz Metering Pulse signal and Enable Hotel Function (EH64).

- Please refer to the Operational Manual of EH64 for the details of the Hotel Function.

Interrelation Zone:      Program Zone 132

## 252 Limit Month Function

**Aristel** ---

252 Limit Month  
TIMES=SS 00→12

**AV**

&lt;-- Program Status Area

&lt;-- SS=00~12

Def.=00

### Description:

## INITIALIZATION

The function will inhibit the outgoing to be made from any internal station during the setting month.

00 = Allowed

01 = Disallowed on January


02 = Disallowed on February

.....

12 = Disallowed on December

Interrelation Zones: None

### 253 Special Warning Tone During HF/Override/Conference Capability




<-- Program Status Area  
<-- SS=00~99  
Def.=0

#### Description:

Defines how many special warning tones will be heard by both internal and external parties if internal party is using handsfree, override or conference mode. The duration between tones is unchanged at 30 seconds. **(This function only for the Italian and Australian markets)**

Interrelation Zones: None

### 254 The Way For SLT To Put the Call On Hold Capability



<-- Program Status Area  
<-- S=0~1  
Def.=0

#### Description:

Allows SLT stations to use the normal method or [FLASH] + [7] to put call on hold.

0 = Disable. SLT station puts the call on hold by HOOK FLASH or pressing [FLASH].

1 = Enable. SLT station puts the call on hold by HOOK FLASH and pressing [7], or pressing [FLASH] and [7]. If SLT hangs up after only HOOK FLASH or pressing [FLASH] the call will be disconnected immediately.

Interrelation Zones: None


### 255 ~ 299 Reserved For Future Use



## ■ System Function - 1 (Zone 300 ~ 399)

Interrelation Zones: None

### 300 Reset Data To Default



&lt;-- Program Status Area

&lt;-- S=1~4

Def.=0

#### Description:

Allows the user to reset the system data.

1 = System data (including the data of EH64) will be reset to the system default with the exception of System Speed Dial.

2 = System data (including the data of EH64) will be reset to the system default.




**All system programming data will be lost.**

3 = Reserved for the future use.

4 = Only the Backup RAM data of EH64 will be reset.

**NOTE 14:** This program can only be carried out by a

### 301 System Password Setup



&lt;-- Program Status Area

&lt;-- NN=01~30

IP=Cursor Position=01~08

#### Description:

Provides up to thirty (30) sets of password for different usage. Each password has a maximum of 16 digits.

#### NN=01

**Programming Password:** The password to enter the system programming.

Default: **dddddddd**

(Refer to System Administrator's Manual)

#### NN=02

#### ■ SMDR Lock/Unlock Password

The password to lock/unlock system's RS232 output. The SMDR data will be stored in the system's memory.

AV-8 = 100 calls

NAV-8 = 100 calls

## INITIALIZATION

AV-12 = 100 calls

AV-38 = 100 calls

AV-64 = 250 calls or 1160 calls (for EH64)

AV-256 = 250 calls or 1160 calls (for EH64)

Default: **ddddddddd**

(Refer to System Administrator's Manual)

### ■ SOS Password (Not available for AV-64 and AV-256)

The password work with [#55] and [#57] to turn on/off the SOS function.

Default: **ddddddddd**

### NN=03

**DISA Password:** The password for DISA callers to access another system free CO line for another outgoing.

Default: **1111dddd**

(Refer to System Administrator's Manual)

### NN=04

**Toll Free Password:** The password to break all Toll Restrictions.

Default: **\_\_\_\_ dddd**

(Refer to System Administrator's Manual)

### NN=05 (Not available for AV-256)

**Incoming Paging Password:** The password for DISA caller to carry out Incoming Paging.

Default: **\_\_\_\_ dddd**

**(Only available when Voice Service interface is installed)**

(Refer to System Administrator's Manual)

### NN=06

**Reserved for future use.**

### NN=07

#### ■ Night Service Password (Only the station in **PROGRAM ZONE 400** can do)

The password to enable the Night Service.

Default: **\_\_\_\_ dddd**

(Refer to System Administrator's Manual)

#### ■ DISA Modem Remote Programming Password

Install RPC card (modem card) in the user's system. Dealer makes an incoming call to the user through DISA line. Dealer presses [#] + [6] + [DISA Modem Password]. The user's system will access (enable) console station in **PROGRAM ZONE 400-07-02** as a Remote Programming Station automatically. Following operation methods will be the same as the method of Remote Programming for PC operation. After the Remote Programming is completed, pressing [\*] by the dealer to cut off the DISA line.

Default: **\_\_\_\_ dddd**

## INITIALIZATION

(Refer to the Operational Manual of SM)

**NN=08**

**Headset Password:** The password to enable Headset function.

Default: \_ \_ \_ \_ dddd

(Refer to System Administrator's Manual)

**NN=09 ~ 30=Reserved for Future Use**


Interrelation Zones: Program Zones 235, 405,

**NOTE 15:** AV-8 = Only one relay, NN = 01.  
NAV-8 = Two relays, NN = 01 ~ 02.  
AV-12 = Two relays, NN = 01 ~ 02.  
**AV-38 = Two relays, NN = 01 ~ 02.**

NN Code	Function	NN Code	Function
00	Non Operation	08	Secret Recording
01	Music On Hold	09	Reserved
02	Door 1 Open	10	External All Zone Page
03	Door 2 Open	11	External Zone 2 Page
04	CO Loud Bell	12	External Zone 2 Page
05	Station Loud Bell	§	§
06	System Alarm	18	External Zone 8 Page
07	Remote Control		

Interrelation Zones: Program Zones 504-ST-4 and

## 302 Relay Function




<-- Program Status Area  
<-- NN=Relay Number NOTE 15  
SS=Relay Function  
Code=00~18  
Def.=[ 02 00 00 00 ]

### Description:

Allows the user to select which functions the system relay can provide.

## 303 Sensor Function



<-- Program Status Area  
<-- IP=Cursor Position NOTE 16  
SS=Sensor Function Code =  
00~18  
(S<sub>1</sub>S<sub>1</sub> = 1st Sensor, S<sub>2</sub>S<sub>2</sub> = 2nd  
Sensor, ..., S<sub>N</sub>S<sub>N</sub> = Nth  
Sensor) NOTE 16  
DD=Control Condition Code =

## INITIALIZATION

**00~01**

**(D<sub>1</sub>D<sub>1</sub> = 1st Sensor, D<sub>2</sub>D<sub>2</sub> = 2nd  
Sensor,....., D<sub>N</sub>D<sub>N</sub> = Nth**

**Sensor) NOTE 16**

**Def.= [ 03 00 00 00 00]**

### Description:

**Sensors are external devices connected to the system and allow the user to select which sensor operations can be controlled by the system.**

<b>NOTE 16:</b>	<p>AV-8 = One sensor; IP=01~02, SS=S<sub>1</sub>S<sub>1</sub> and DD=D<sub>1</sub>D<sub>1</sub></p> <p>NAV-8 = Two sensors; IP=01~04, SS=S<sub>1</sub>S<sub>1</sub>~S<sub>2</sub>S<sub>2</sub> and DD=D<sub>1</sub>D<sub>1</sub>~D<sub>2</sub>D<sub>2</sub></p> <p>AV-12 = Two sensors; IP=01~04, SS=S<sub>1</sub>S<sub>1</sub>~S<sub>2</sub>S<sub>2</sub> and DD=D<sub>1</sub>D<sub>1</sub>~D<sub>2</sub>D<sub>2</sub></p> <p>AV-38 = Two sensors; IP=01~04, SS=S<sub>1</sub>S<sub>1</sub>~S<sub>2</sub>S<sub>2</sub> and DD=D<sub>1</sub>D<sub>1</sub>~D<sub>2</sub>D<sub>2</sub></p> <p>AV-80 = Four sensors; IP=01~08, SS=S<sub>1</sub>S<sub>1</sub>~S<sub>4</sub>S<sub>4</sub> and DD=D<sub>1</sub>D<sub>1</sub>~D<sub>4</sub>D<sub>4</sub></p> <p>AV-256 = Sixteen sensors; IP=01~17,</p>
-----------------	---

### ● Fire Alarm Application:

When sensor is triggered all idle stations will ring continuously and all busy stations will hear the alarm tone. To cancel Fire Alarm, lift the handset and press **[#] + [5] + [2]**.

### ● Break In Alarm Application:

When sensor is triggered all idle stations will ring continuously and will stop ringing when the signal ceases.

### ● SOS Application:

As soon as the sensor is triggered the system will disconnect all the existing engaged lines and make outgoing calls through SPD according to **PROGRAM ZONE 243** and **404**. The message text of "SOS" will be displayed on the LCD key telephone. Operate the following codes from the station in **PROGRAM ZONE 400** can turn on/off the SOS function:

**[#]+[5]+[5]+[Password in PROGRAM ZONE 301-02]** = Turn Off SOS function.

**[#]+[5]+[7]+[Password in PROGRAM ZONE 301-02]** = Turn On SOS function.

## INITIALIZATION

Table 1		Table 2	
SS	Function	DD	Sensor Type
00	Non Operational	00	Low Level Control
01	Fire Alarm (Continuous Alarm)	01	High Level Control
02	Break In Alarm (Interrupted Alarm)	<ul style="list-style-type: none"><li>● Low level means Normal Close</li><li>● High level means Normal Open</li></ul>	
03	Door 1 Switch Sensor		
04	Door 2 Switch Sensor		
05	Relay Enable <small>NOTE 17</small>		
06	SOS Sensor		
07	SOS and Relay <small>NOTE 17</small>		
08~18	Reserved		

**NOTE 17: 05 = Relay Enable**


---> Once the sensor is triggered the symmetrical relay will be enabled.

**Eg:    Sensor 1 enables Relay 1,  
Sensor 2 enables Relay 2, etc.**

## 07 = SOS and Relay

**Interrelation Zones: Program Zones 124, 243, 404, 301-02 and System**

## 304 Date And Time



### Description:

Sets system Date and Time and is controlled by the System's Real Time Clock. Users can see the current date and time displayed on the LCD. **(If format of Date for Australian market = dd/mm/yy)**

**mm** = Month = 01 ~ 12

**dd** = Day = 01 ~ 31

**yy** = Year = 00 ~ 99

**W** = Week = 1 ---> Monday

= 2 ---> Tuesday

= 3 ---> Wednesday

= 4 ---> Thursday

= 5 ---> Friday

= 6 ---> Saturday


= 7 ---> Sunday

**HH** = Hour = 00 ~ 23

**MM** = Minute = 00 ~ 59

Interrelation Zone: Program Zone 204

## 305 System Alarm Clock



<--Program Status Area  
 <--NN=Alarm Schedule  
 Number=01~10  
 IP =Cursor Position  
 Number=01~03

### Description:


The system provides ten (10) different time settings. All idle key stations will be activated by background music through the telephone speakers as soon as the alarm time is reached. If the system is installed with all SLTs

01=Alarm Time Schedule 1 ..... 10=Alarm Time Schedule 10

- **hh** = Hour (00~23)
- **mm** = Minute (00~59)
- **dd** = Duration(00~99)

Interrelation Zone: Program Zone 206

## 306 Day Time Schedule



<-Program Status Area  
 <-NN=Day Schedule  
 Number=00~06  
 IP=Cursor Position  
 Number=01~03  
 Def.= [ 00:00 to 00:00 ] except  
 Sunday

### Description:

Allows the user to set up Day Time Duration to let the system divide day and night time automatically when Day/Night switching is in Auto Mode.

### ● Time setting

hh = Starting Hour Number = 00 ~ 23  
 mm = Starting Minute Number = 00 ~ 59  
 HH = End Hour Number = 00 ~ 23  
 MM = End Minute Number = 00 ~ 59

If hh:mm = HH:MM means it is in the Night Service.

### ● Weekly Day setting


NN = 00 = Sunday

## INITIALIZATION

NN = 01 = Monday  
NN = 02 = Tuesday  
NN = 03 = Wednesday  
NN = 04 = Thursday  
NN = 05 = Friday  
NN = 06 = Saturday  
NN = 07 = Sunday

**Interrelation Zones:** Program Zones 503-ST-5,  
503-ST-6, 600, 601, 604-CO-3,  
604-CO-5, 604-CO-7, 604-CO-8

## 307 SMDR Report



<-- Program Status Area  
<-- P=Cursor Position  
Number=1~8

### Description:

Station Message Detail Record specification which determines the characteristics of the detail report about each incoming or outgoing call.

### P = 1 = Recording Start Time = 0 ~ 9 ---> "Start Time"

The system will start to count the call duration as soon as the setting time is reached after the CO line is accessed.

0 = 00 seconds, 1 = 05 seconds, ....., 7 = 35 seconds, 8 = 40 seconds, 9 = 45 seconds

### P = 2 = Incoming Call Record = 0 ~ 1 ---> "Rec\_Incom"

Incoming calls will be recorded by the system.

0 = Not Record      1 = Record

### P = 3 = Local call record = 0 ~ 1 ---> "Rec\_Local"

Local calls will be recorded by the system.

0 = Not Record      1 = Record

(Refer to Program Zone 206)

### P = 4 = Incoming Call No Answer Record = 0 ~ 1 ---> "Rec\_NoAns"

Whether to record incoming calls which are not answered.

0 = Not Record      1 = Record

## INITIALIZATION

**P = 5 Print Out The Title = 0 ~ 1 ---> "Rec\_Title"**

Whether to print out the title.

0 = Not Print      1 = Print

**P = 6 = Number Of Record between Titles = 00 ~ 99 ---> "Title\_No"**

Total numbers of records between two titles in the report.

**P = 7 = Polarity Reverse = 0 ~ 1 ---> Polarity**

Polarity Reverse is a reverse signal sent from the Central Office after the external called party answers. If the function is enabled the system will start to count the time of the outgoing call after the called party answers.

**(This function is not available in AV-8/NAV-8/AV-16H)**

0 = Disable      1 = Enable

**P = 8 = RS232 Output Port = 1 ~ 4 ---> SMDR Cabin**

Determines which serial printer or computer is connected to A2RSCA (RS232 interface) in which cabinet.

**(This function is only available in AV-256)**

1 = 1<sup>st</sup> cabinet,    2 = 2<sup>nd</sup> cabinet,    3 = 3<sup>rd</sup> cabinet,

4 = 4<sup>th</sup> cabinet

### ***SMDR OUTPUT DATA FORMAT***

<u>CO</u>	<u>Ext</u>	<u>S</u>	<u>Telephone Number</u>	<u>Account</u>	<u>MM/DD</u>	<u>Start</u>	<u>Duration</u>	<u>Ring</u>
01	12		0088629993380	9125	12/01	08:35	00:05'35"	
05	15	X	123567890		12/01	09:00	00:09'45"	
02	17	D	Incoming	1111	12/01	09:10	00:05'19"	00'02"
03	NN		Incoming No Answer		12/01	10:00		00'30"
04	13	#	Incoming		12/01	10:09	00:00'15"	00'03"
04	11	*	Incoming		12/01	10:11	00:03'10"	
01	d-03	d	090901123		12/01	12:00	00:10'45"	
06	14		0088626522222	FAC:01	12/01	12:30	00:04'45"	

### **Title Illustration**

<b>Ext</b>	= Station Number	<b>X</b>	= Cut by restriction
<b>CO</b>	= CO Number	<b>Telephone Number</b>	= 24 digit maximum
<b>S</b>	= Control Status	<b>Account</b>	= 8 digit maximum
<b>D</b>	= DISA Incoming	<b>MM/DD</b>	= Month/Day
<b>d</b>	= DISA Outgoing	<b>Start</b>	= Time to access a CO line (hh:mm)
<b>#</b>	= Hold	<b>Duration</b>	= Time duration of the call (hh:mm:ss")
<b>*</b>	= Answer call on hold	<b>Ring</b>	= Incoming ringing time (mm:ss")



**Case Illustration: (Date: December 01)****Case 1:**

08:35, Station 12 made a 5 minutes 35 seconds call (Tel. No. 0088629993380) through line 1 and stored Account No. 9125.

**Case 2:**

09:00, Station 15 made a call through line 5 but was restricted.

**Case 3:**

09:10, DISA incoming call through line 3, call duration 5 minutes 19 seconds.

**Case 4:**

10:00, incoming call through line 3 rang for 30 seconds. No answer and call abandoned.

**Case 5:**

10:09, incoming call through line 4 rang for 3 seconds and answered by Station 13. After 15 second conversation call placed on hold.

**Case 6:**

10:10, Station 11 retrieved held call, placed on hold by Station 13, on line 4.

**Case 7:**


12:00, incoming call through line 3 used DISA function and made another outside call to 09091123 by line 1. Duration time is for line 1.

**Case 8:**

12:30, Station 14 made a Toll call through line 6 by Forced Account Code 01.

Interrelation Zone: Program Zone 228

## 308 Midday Time



<--Program Status Area

<--NN=Midday Schedule

Number=00~06

IP =Cursor Position

Number=01~03

Def.=[ 00:00 to 00:00 ]

**Description:**

- With Voice service interface installed the program allows users to set up the Midday Time Duration. Incoming calls will not ring to internal stations during the setting time but LED for the incoming line will still flash.
- Without Voice Service interface installed all incoming calls will ring only to the stations assigned in **PROGRAM ZONE 601-01-IP (IP=09 ~ 16)**.
- **Time Setting:**  
**hh** = Starting Hour Number = 00 ~ 23  
**mm** = Starting Minute Number = 00 ~ 59

## INITIALIZATION

**HH** = End Hour Number = 00 ~ 23

**MM** = End Minute Number = 00 ~ 59

- **Weekly Day Setting:**

NN = 00 = Sunday

NN = 01 = Monday

NN = 02 = Tuesday

NN = 03 = Wednesday

NN = 04 = Thursday

NN = 05 = Friday

NN = 06 = Saturday

NN = 07 = Sunday


Interrelation Zones: Program Zones 219, 402, 600

---

**309 ~ 399**      **Reserved For Future Use**

## ■ System Function - 2 (Zone 400 ~ 499)

### 400 Console Arrangement



<--Program Status Area  
 <--SSSS= Station Number  
       = 2~4 digits  
 GP=Group Number=01~08  
 IP=Cursor Position=01~04  
 Def.=[11 12 13 14]

#### Description:

The program assigns console stations in eight (8) groups. Any station can dial [0] or [9] to call the first available station in the same console group.

- The station position **IP=01** in each group is the Master Console for that group.

#### FOLLOWING CONSOLES ARE SPECIAL USED IN SOME PURPOSES:

- **400-04-IP:**  
**PROGRAM ZONE 219=5**, during the Midday Time the DISA call

(according to the conditions in **PROGRAM ZONE 218**) will be transferred to the assigned consoles here. The consoles will not ring but have an Alert Tone to be heard from the speaker.

- **400-05-IP: (Not available in AV-8/NAV-8/AV-16H/AV-24)**  
 After System Wide CFW function is enabled, the call to the Busy or No Answer internal station will be forwarded to the first free console station here. The **Hunting** function is provided here automatically. The function is very useful for the Voice Mail application.
- **400-06-IP:**  
**PROGRAM ZONE 219=5**, during the Night Time the DISA call (according to the conditions in **PROGRAM ZONE 218**) will be transferred to the assigned consoles here. The consoles will not ring but have an Alert Tone to be heard from the speaker.
- **400-07-01:**  
 If the assigned station is SLT and **PROGRAM ZONE 218** is enabled, DISA calls will be transferred to the assigned SLT station here after the system has checked the consoles for three (3) times if the call still is not answered. Once DISA call is transferred to the assigned SLT station the rechecking cycle will be the same as **PROGRAM ZONE 218**. You are recommended to assign the Answering Machine or Voice Mail to be used for the caller to leave the messages.

## INITIALIZATION

- **400-07-02:**

Dealer makes an incoming call to the user's system through DISA line for Remote Programming function and is answered, the user's system will access (enable) the console station here as Remote Programming station as soon as the dealer pressing [ # ] + [6] + [DISA Modem Password].

- **400-07-03: (Only available in NAV-8 with A3VSCB)**

Incoming call through the **VOICE DISA (Auto Attendant operated by A3VSCB)** and answered by the system, if the system detects the FAX signal whilst playing the Greeting Message, the call will be transferred to the assigned SLT station automatically. If the system does not detect any FAX signal, the operation will be the same as the normal Auto Attendant operation.

- **400-08-01:**

**PROGRAM ZONE 246=2 (or 3)**, only the assigned key station here can Record and Play the Voice Messages on the Voice Service Unit.

- **400-GP-01:**

Station dials [9] (or [0]) to call consoles which consoles' group is the same as the Station Group of the calling station in **PROGRAM ZONE 503-ST-1**, if all of the consoles in that group

are busy the calling station can press [MSG] (or [6]) to leave the message to the first console.


- **400-GP-04:**

Station dials [9] (or [0]) to call consoles which consoles' group is the same as the Station Group of the calling station in **PROGRAM ZONE 503-ST-1**, if all of the consoles in that group are busy the calling station can press [1] to ring to the last console and the Ringing Reminder can be heard from the speaker of the console's telephone.

**Interrelation Zones: Program Zones 122, 201, 218, 219,**

---

## 401 One Digit Dialing (ODD) Function



<-- Program Status Area

<-- **SSSS=Station Number**  
= 2~4 digits

**GP=Group Number=01~08**

**IP=Cursor Position=01~08**

**Def.=[00 00 00 00 00 00 00]**

### Description:

Allows the user to call intercom by dialing one setting numerical digit. It is useful for Hotel/Motel applications. A total of eight (8) numerical


digits can be used individually in each group.

#### EXAMPLE:

**IP = 01~08** Stations positioned here can be called by dialing numerical digit **[1] ~ [8]**.

Interrelation Zone: Program Zone 209

## 402 Voice Service



<-- Program Status Area  
 <-- **SS=Voice Function Code =**  
**01~20**  
**NN=Voice Channel Number**  
 NOTE 18  
**IP=Cursor Position=01~20**  
**Def.=[00 00 00 00..... 00 00**  
**00 00]**

#### Description:

Allows the user to divide each voice service channel of the optional Voice service Card into a maximum of 20 sub-channels with different function requirements.

- **IP = Cursor Position Number**

IP = 01 = Sub-channel number 1.

IP = 02 = Sub-channel number 2

.....

IP = 20 = Sub-channel number 20

- Assign each Voice section as one of the following 20 functions.
- If the Voice Channel is used for DISA line in AV-64/AV-256, it is necessary to assign the Voice Channel number in **PROGRAM ZONE 600 and 601** to be the incoming call station. It is not necessary to repeat this step in AV-8/NAV-8/AV-16H/AV-24/AV-38.

**NOTE 18: AV-8/NAV-8/AV-12** =There is only one Voice Service Channel.

**NN = 01** = The 1st Voice Service Channel. (Channel number = **[# 6 3]**)

**AV-38** =There is a maximum of two Voice Service Channels.

**NN = 01** = The 1st Voice Service Channel. (Channel number = **[# 6 3]**)

**NN = 02** = The 2nd Voice Service Channel. Channel number = **[# 6 4]**)

**AV-64** = There is a maximum of 12 Voice Service Channels.

**NN = 01** = The 1st Voice Service Channel.....

**NN = 12** = The 12th Voice Service Channel.

**AV-256** = There is a maximum of 40 Voice Service Channels.

**NN = 01** = The 1st Voice Service Channel. ....

**NN = 40** = The 40th Voice Service Channel.

**(Channel number of AV-64 and AV-256 is assigned in Program Zone 502-CSN-1)**


## INITIALIZATION

### Voice Service Table

Function Code SS	Function Illustration
00	No Operation
01	Company Greeting Message
02	Station Busy Message
03	Non Existent Station Message
04	All Consoles Busy Message
05	No Answer Message
06	Holding Message
07	Voice Service Ending Message
08 ~ 15	Reserved For Future Use
16	The second ACD Reminding Message
17	The first ACD Reminding Message
18	Midday Message
19	Holiday (or Off Duty) Message
20	Wake Up Call Message

**Interrelation Zones:** Program Zones 211, 221,  
306, 308, 502-CSN-1, 600, 601,

### 403 Forced Account Code (FAC)



<--Program Status Area

<--NN=Forced Account

**Code** NOTE 19

**IP=Cursor Position=01~08**

**Def.= [ \_ddddddd ]**

#### Description:

Allows the user to temporarily break through Toll Restriction. A maximum of 8 digits can be entered.

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	dddddddd	Clear all digits
DSS15	_	Clear a specific digit
DSS20	d	Allows any digit to be used

## INITIALIZATION

**NOTE 19:** **AV-8/NAV-8** = There are a maximum of 26 sets of Forced Account Codes.  
**NN = 01 ~ 26**

**AV-12/38** = There are a maximum of 26 sets of Forced Account Codes.  
**NN = 01 ~ 26**

**AV-64** = There are a maximum of 64 sets of Forced Account Codes.  
**NN = 01 ~ 64**

**AV-256** = There are a maximum of 99 sets of Forced Account Codes.  
**NN = 01 ~ 99**

Interrelation Zones Program Zones 507-ST-3

according to the Speed Dial Code only without Name Speed Dialing provided here.

- A total of 30 digits can be entered in each Speed Dialing Code.
- If Automatic SOS is enabled, NNN = 111~118 will become the outgoing numbers of CO1~CO8.

### NOTE 20:

- 1. AV-8/NAV-8** = There are 600 sets of Speed Dial Codes. **NN = 100 ~ 699.**  
**AV-12/38** = There are 600 sets of Speed Dial Codes. **NN = 100 ~ 699**  
**AV-64/256** = There are 900 sets of Speed Dial Codes. **NN = 100 ~ 999**
- 2. AV-8/NAV-8** --- > TT = CO line number = 01 ~ 03  
**AV-12** --- > TT = CO line number = 01 ~ 04  
**AV-38** --- > TT = CO line number = 01 ~ 08  
**AV-64** --- > TT = CO line number = 01 ~ 20  
**AV-256** --- > TT = CO line number = 01 ~ 40

If **TT = 00** then the system will select a free CO line for SPD according to the assigned Dial [9] group in **PROGRAM ZONE 503-ST-3 and 603**. Pressing **[DSS5]** key can change the assigned CO number TT.

## 404 Speed Dial Code Assignment

**Aristel** ---

404
CO:TT

NNN-IP

**AV**

<--Program Status Area  
 <--NNN=Speed Dial Code NOTE 20  
 IP=Cursor Position=01~30  
 Def.=Without any entry

### Description:

Allows the user to enter the desired telephone number into the system database for memory back-up. System Speed Dialing is

### Name Speed Dialing:

If **PROGRAM ZONE 227 = 1** enables Name Speed Dial Function, the speed dial code can be replaced by a personal name. Pressing **[DSS5]** will change Speed Dial Code status to Name Entrance status.

## INITIALIZATION

For Name Entrance status, dial the following numerical key on the key phone to enter letter. Once one letter is entered press [DSS3] to go back to the previous position or press [DSS4] to go forward to the next position to set another letter.

**A** = [2]      **B** = [2][2]      **C** = [2][2][2]      **D** = [3]  
**E** = [3][3]      **F** = [3][3][3]      **G** = [4]      **H** = [4][4]  
**I** = [4][4][4][4]      **J** = [5]      **K** = [5][5]      **L** = [5][5][5]  
~~**M** = [6]~~      ~~**N** = [6][6]~~      ~~**O** = [6][6][6]~~      ~~**P** = [7]~~  
**Q** = [1] or [7][7]      **R** = [7][7][7]      **S** = [7][7][7][7]      **T** = [8]  
**U** = [8][8]      **V** = [8][8][8]      **W** = [9]      **X** = [9][9]  
**Y** = [9][9][9]  
**Z** = [1][1] or [9][9][9][9]      Abbreviating dot " • " = [0]

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS15	F	Flash
DS20	Blank	Clear the current digit
DSS23	p	Pause
DSS24	T	Pulse to Tone (DTMF)


**Pause** : A temporary stop in dialing (see **PROGRAM ZONE 100** and **232**).

**Flash** : A loop disconnection for a re-determined duration.

**Pulse to DTMF** : Change of signaling from Pulse to DTMF.

**Interrelation Zones: Program Zones 100, 225, 227**

## 405 Toll Group Assignment



<--Program Status Area

<--NN=Toll Group Number

=00~09

IP=CO Number=01~08

### Description:

The following function table is for the cross reference that defines which kind of dialing capability for each CO line can be operated on each station. The table explains the theory of toll restriction operation.

- There are ten (10) valid groups
- IP = CO line number
- There are ten (10) Toll Layers that can be assigned to each CO line in each Toll Group.

### Toll Layers:

Layer	Function	Interrelation
0	Unrestricted	
1	Dialed local numbers assigned length	Zone 206
2	Can only dial Common Allowed Code	Zone 406
3	Can dial any numbers except Common Disallowed Code	Zone 407
4	Allowed to dial numbers with Allowed Area Code A,	Zones 408/410



## INITIALIZATION

	Office Code A	
5	Allowed to dial numbers with Allowed Area Code B, Office Code B	Zones 409/411
6	Allowed to dial numbers with Allowed Area Code A+B, Office Code A+B	Zones 408/409/410/411
7	Toll Private Line	
8	Cannot access the trunk line	
9	Reserved	

Interrelation Zones: Program Zone 203, 503-ST-5

Key	LCD Display	Description
DSS10	ddddddddd	Clear all digits
DSS15	—	Clear a specific digit
DSS20	d	Allows any digit to be used.


### EXAMPLE:

406 Allowed 01-IP -----	406 Allowed 02-IP 0 7 7 4 9 5 5 4 4 _ _	406 Allowed 03-IP 0 6 0 d d d d d d d d d
----------------------------	--	--

Code 01: No numbers allowed  
Code 02: Allow only number [077495544]  
Code 03: Allow numbers beginning with [060]

Interrelation Zone: Program Zone 405

## 406 Common Allowed Code




<--Program Status Area  
<--NN=Allow Code NOTE 21  
IP=Cursor Position=01~11

### Description:

Allows the telephone number assigned here to be unrestricted, even when the dialing station is restricted by Toll Restriction.

- Common Allowed Code is the second priority in any Toll Restriction.
- A total of 11 digits can be entered in each Allowed Code.
- Key Functions:

## 407 Common Disallowed Code



<--Program Status Area  
<--NN=Disallowed  
Code NOTE 21  
IP=Cursor Position=01~11

### Description:

Prevents the telephone number assigned here being dialed, even if the dialing station is unrestricted by Toll Restricted.

## INITIALIZATION

- Common Disallowed Code is the first priority in any other Toll Restriction.
- A maximum of 11 digits can be entered in each Allowed code
- Key Functions.

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	ddddddddd	Clear all digits
DSS15	_	Clear a specific digit
DSS20	d	Allows any digit to be used


### EXAMPLE:

407 Disall 01-IP -----	407 Disall 02-IP 077495544__	407 Disall 03-IP 060ddddddddd
---------------------------	---------------------------------	----------------------------------

Code 01: No numbers Disallowed  
 Code 02: Disallow only number **[077495544]** beginning with **[060]**  
 Code 03: Disallow numbers

Interrelation Zone: Program Zone 405

## 408 Area Code - A



<--Program Status Area

<--NN=Area Code NOTE 21

IP=Cursor Position=01~03

### Description:

Area numbers are followed by Toll Access Code (**PROGRAM ZONE 203**). Allows unrestricted dialing by any station in Toll Layers 5 and 6 of Area numbers assigned here.

- A maximum of three (3) digits can be entered in each Code.
- Set up Toll Access Code beforehand. (Program Zone 203)
- Key Functions:

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	ddddddddd	Clear all digits
DSS15	_	Clear a specific digit
DSS20	d	Allows any digit to be used.

### EXAMPLE:


408 Area_A 01-IP 69d	408 Area_A 02-IP d__	408 Area_A 03-IP ---
-------------------------	-------------------------	-------------------------

## INITIALIZATION

Code 01:	Code 02:	Code 03:	DSS15	—	Clear a specific digit
Area Code beginning	Any Area Codes are	Without any Area	DSS20	d	Allows any digit to be used.
with <b>[Toll Access Code]</b>	allowed	Codes are allowed			
<b>+ [69]</b> are allowed					

**Interrelation Zone:    Program Zone 203 and 405**

### 409    Area Code - B



<--Program Status Area  
 <--NN=Area Code NOTE 21  
 IP=Cursor Position=01~03

#### Description:

Area numbers are followed by Toll Access Code (Program Zone 203). Allows unrestricted dialing by any station in Toll Layers 5 and 6 of Area numbers assigned here.

- A maximum of 3 digits can be entered in each Code.
- Set up Toll Access Code beforehand. (Program Zone 203)
- Key Functions:

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	ddddddd	Clear all digits


#### EXAMPLE:

409 Area_B 01-IP 69d	409 Area_B 02-IP d__	409 Area_B 03-IP _ _ _
-------------------------	-------------------------	---------------------------

Code 01:	Code 02:	Code 03:
Area Code beginning	Any Area Codes are	Without any Area
with <b>[Toll Access Code]</b>	allowed	Codes are allowed
<b>+ [69]</b> are allowed		

**Interrelation Zone:    Program Zone 203 and 405**

### 410    Office Code - A



<--Program Status Area  
 <--NN=Office Code NOTE 21  
 IP=Cursor Position=01~03

#### Description:

Office numbers A are 3 digits followed by Area Code (Program Zone 408). Allows unrestricted dialing by any station in Toll Layers 4 and 6 of Office numbers assigned here.

## INITIALIZATION

- A maximum of 3 digits can be entered in each Code.
- Set up Toll Access Code and Area Code A beforehand.  
**PROGRAM ZONE 203 and 408) .**
- Key Function:

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	ddddddddd	Clear all digits
DSS15	_	Clear a specific digit
DSS20	d	Allows any digit to be used.


### EXAMPLE:

410 Office_A 01-IP 69d	410 Office_A 02-IP d__	410 Office_A 03-IP _ _ _
---------------------------	---------------------------	-----------------------------

Code 01:	Code 02:	Code 03:
Office Codes beginning With <b>[69]</b> are allowed	Any Office Codes are allowed	Without any Office Codes are allowed

**Interrelation Zone:      Program Zone 203, 405 and**

## 411      Office Code - B



<--Program Status Area  
<--NN=Office Code NOTE 21  
IP=Cursor Position=01~03

### Description:

Office numbers A are followed by Area Code A (Program Zone 408). Allows unrestricted dialing by any station in Toll Layer 5 and 6 of Office numbers assigned here.

- A maximum of 3 digits can be entered in each Code.
- Set up Toll Access Code and Area Code A beforehand.
- Key Function:

<u>Key</u>	<u>LCD Display</u>	<u>Description</u>
DSS10	ddddddddd	Clear all digits
DSS15	_	Clear a specific digit
DSS20	d	Allows any digit to be used.

**NOTE 21:AV-8/NAV-8 --- > NN = 01 ~ 30**  
**AV-16H/24/38 --- > NN = 01 ~ 30**

## INITIALIZATION

### EXAMPLE:

411 Office\_B 01-IP  
69d

411 Office\_B 02-IP  
d \_ \_

411 Office\_B 03-IP  
\_ \_ \_

Code 01:                      Code 02:                      Code 03:  
Office Codes beginning Any Office Codes Without any Office  
With **[69]** are allowed are allowed Codes are allowed


**Interrelation Zone:      Program Zone 203, 405 and**

---

**412 ~ 499    Reserved For Future Use**

## ■ Station Function (Zone 500 ~ 599)

### 500 Key Group Assignment (For KP)



<--Program Status Area

<--GP = 01~08, IP = 01~25

#### Description:

Assigns eight (8) groups of Flexible DSS keys for Key Phone and each Key Phone can be assigned to one group.

- Each key can be assigned as either a **CO** or **Station** or **Function** or **SPD**.
- Pressing [DSS5] key can change **CO** to **Station** or **Function** or **SPD**.

**NNNN** can be either one of the following settings:

1. **CO:NN** = The display for the user to assign each DSS Key as a CO line key.

**CO** = CO line number NOTE 22

<b>NOTE 22:</b>	<b>AV-8/NAV-8</b>	→ CO=01 ~ 03
	<b>AV-12</b>	→ CO=01 ~ 08
	<b>AV-38</b>	→ CO=01 ~ 12
	<b>AV-64</b>	→ CO = 01 ~ 20
	<b>AV-256</b>	→ CO = 01 ~ 40

2. **NNNN** = The display for the user to assign each DSS Key as a Station key. **Station Number can be two (2) to four (4) digits.**

3. **FN:NN** = The display for the user to assign each DSS Key as a Function key.


**FN** = Function Code (00 to 99) Please refer to "Definition of Function Code Table".

4. **SPD:NNN** = The display for the user to assign each DSS Key as a Speed Dial key. **(SPD DSS Key is only available for DSS64 Phone in PROGRAM ZONE 501, and useless for Key Phone in PROGRAM ZONE 500)**

Interrelation Zones: Program Zone 503-ST-02 and

### 501 Key Group Assignment (For DSS)

The programming is the same as PROGRAM ZONE 500 except for DSS64 phone and is available for AV-24/AV-38/AV-64/AV-256.



<--Program Status Area

<--GP = 01~08, IP = 01~64

# INITIALIZATION

## Definition of Function (FN) Code:

Code	Function	Code	Function
00	Non-Operational	39	Paging Zone 8
01	Message Waiting/Pulse to Tone Change over	40	Paging External Zone
02	Do Not Disturb/Conference	41	Paging External Zone 1
03	MICrophone/Auto Answer	42	Paging External Zone 2
04	Save	43	Meet Me Paging
05	Account Code	44	Pick Up All Group
06	Call Forward	45	Pick Up Own Group
07	Call Forward All	46	Pick Up Group
08	Call Forward Busy	47	Pick Up Group 1
09	Call Forward No Answer	48	Pick Up Group 2
10	Call Forward Busy/No Answer	49	Pick Up Group 3
11	Follow Me	50	Pick Up Group 4
12	Security Code	51	Pick Up Group 5
13	Temporary Security Code	52	Pick Up Group 6
14	Set Macro Function	53	Pick Up Group 7
15	Set Voice	54	Pick Up Group 8
16	Individual Alarm (Station)	55	Pick Up Station
17	Individual Alarm (Console)	56	Pick CO line
18	Date/Time (Console)	57	Auto Find CO line
19	Help List	58	Baby Monitoring
20	System Program	59	Fire Alarm Off
21	Speed Dial	60	Lock/Unlock SMDR Output
22	Console Speed Dial (System)	61	Open Door/Door Status 1
23	Console Speed Dial (Individual)	62	Open Door/Door Status 2
24	Morning Call (Assign Alarm)	63	VSU 1
25	Day/Night Service	64	VSU 2
26	Outgoing Message	65	Call Park
27	Toll Password	66	Split/Swap
28	Paging All	67	Morning Call
29	Paging All Internal	68	Check In
30	Paging All External	69	Check Out
31	Paging Zone	70	Calculator
32	Paging Zone 1	71	Call Door 1
33	Paging Zone 2	72	Call Door 2
34	Paging Zone 3	73	Monitor Station
35	Paging Zone 4	74	Setting CO Name Speed Dial
36	Paging Zone 5	75	Security Recording
37	Paging Zone 6	76	Setting Extension Name
38	Paging Zone 7	77	[FN=74]+[1]

Code	Function	Code	Function
78	[FN=74]+[2]	86	Reset the Time Counter During the External Call
79	[FN=74]+[3]	87	Delete Saved Numbers Manually (for 5 different numbers save redial function) <small>NOTE 23</small>
80	The 1st ↔ the 2nd DSS Key Page	88	Remote Programming Code with Modem ([SPD]+[FUNC]+[6])
81	Ringing Volume Level Control	89	Remote Programming Code without Modem <small>NOTE 24</small>
82	Speaker Volume Level Control	90	Account Code <small>NOTE 25</small>
83	Handset Volume Level Control	91	Reserved
84	Ringing Frequency Control	92	CLI Saved Numbers Display <small>Refer to UF-CND Operational Manual</small>
85	Auto (Save) Redial <small>NOTE 23</small>		

## Definition of Function (FN) Code:

**NOTE 23:****OPERATION EXAMPLE:**

- **5 Numbers Auto Redialing Operation (only Key Phone can do, and must under handsfree dialing)**
  - Step 1.** Accessing a free CO line from key station.
  - Step 2.** Dialing the desired telephone number and pressing [SAVE] during hearing busy tone or ring back tone, and then disconnect CO line.
  - Step 3.** Repeat **Step 1** and **Step 2** till all the desired numbers are dialed and saved (**5 different numbers maximum**).
  - Step 4.** Pressing DSS Key as [**FUNC=85**] starting to do Auto-Redial.
  - Step 5.** The system will start to re-cycle the stored numbers for auto-redialing till the function is disabled by pressing [SPK] button whilst hearing busy tone or ring back tone or the numbers are redialing.
  
- **Delete the stored number automatically (only Key Phone can do, and must under handsfree dialing)**
  - Step 1.** If the called number is answered, lifting up the handset from key station.
  - Step 2.** After key station hangs up the handset, the number of in **Step 1** will be canceled from the memory automatically, and other stored numbers will be remained.
  
- **Delete the stored number manually (only LCD Key Phone can do, and must under handsfree dialing)**
  - Step 1.** On hook, pressing DSS Key as [**FUNC=87**] will see the following display:
 

**1. AUTO. CLEAR ALL :**  
Will clear all the telephone numbers in the memory for Auto Redial.

1. AUTO. CLEAR ALL  
2. DISPLAY TEL

**2: DISPLAY TEL. :**  
Will see the following 2nd display:

3.NEXT 4.CANCEL  
((SAVED NUMBERS))

You can cancel the telephone number one by one.



**NOTE 24:****OPERATION EXAMPLE:**

**Step 1.** No matter which the dealer makes outgoing call to the user or the user makes incoming to the dealer.

**Step 2.** During external conversation, the user presses DSS key as **[FUNC=89]** to allow the dealer to enter to the user's system remotely and the user will see the following display from the user's own display key phone:

SYSTEM	FUNCTION
ENTER	PASSWORD

Meanwhile, the user can tell the dealer the display message as above and then hangs up the handset.

**Step 3.** The Dealer presses [SPK] button and hangs up the handset to start to key-in the Programming Password to enter the user's system programming which is the same method as from the dealer's own LCD key phone locally. All the operation codes during the programming should be replaced by the following codes:

[#] = SAVE

[\*]+[\*] = EXIT

[\*]+[0] = FUNC

[\*]+[1] = UP (forward to the next zone)

[\*]+[2] = DOWN (backward to the previous zone)

[\*]+[3] = LEFT (shift the cursor to the left position)

[\*]+[4] = RIGHT (shift the cursor to the right position)

[\*]+[5] = CHANGE (change the function condition of DSS key in zone 500 and 501)

[\*]+[6] = CLEAR ALL (clear all the digits to be 0 in the current zone area)

[\*]+[7] = CLEAR DIGIT

[\*]+[8] = DON'T CARE

[\*]+[9] = PAUSE

**Step 4.** Once the dealer pressing [\*] + [\*] to quit from the programming, the user's phone will start to ring immediately till it is answered and hung-up.

**NOTE 25:** During the external conversation, the internal user can press DSS key as **[FUNC=90]** to start to enter the Account

## 502 Station Function - Port Parameter

**Aristel** ---

502	Ext.	No	P
SSSS			

**AV**

<--Program Status Area

<--P = 01~07 = Item

**SSSS = Station Number**

**CSN = Port Number** NOTE 26

**Description: (P = 1 ~ 7)**

**P = 1 = Station Number** ----> "Station No"

**SSSS = 2 ~ 4 digits (Can be used at the mix-up)** NOTE 27

If the Voice channel Number setting is in AV-64/AV-256 only the first four (4) ports are needed to assign the number. This means that CSN=CS5 ~ CS8 will always be "0000".

### NOTE 26:

**AV-8/NAV-8** ----> C = No Entry  
S = 1  
N = 1 ~ 8

**AV-12** ----> C = No Entry  
S = 1 (the 1st station card)  
= 2 (the 2nd station card)  
N = 1 ~ 8 = ports 1 ~ 8

**AV-38** ----> C = No Entry  
S = 1 (the 1st station card)  
= 2 (the 2nd station card)  
= 3 (the 3ns station card)  
= 4 (if installed with SLC )  
N = 1 ~ 8 = ports 1 ~ 8

**AV-64** ----> C = 1 = only one cabinet  
S = 1 ~ 9 = slots 1 ~ 9  
N = 1 ~ 8 = ports 1 ~ 8

### Very important:

S = 10 can not be entered. You can enter the last existing port number and then press [SAVE] from key phone to enter the 1st port of the 10th slot.

**AV-256** ----> C = 1 ~ 4 = cabinets 1 ~ 4  
S = 1 ~ 8 = slots 1 ~ 8  
N = 1 ~ 8 = ports 1 ~ 8

## INITIALIZATION

### NOTE 27:

1. If **PROGRAM ZONE 205 = 4**, then 2 digits **[nn]** and 3 digits **[mmm]** station number must be assigned as **[00nn]** and **[0mmm]**, can not be assigned as **[nn00]** and **[mmm0]**.
2. Even though the assigned station number is **[00nn]** and **[0mmm]**, the caller still can dial **[nn]** and **[mmm]** to call the desired station. But the display will show the station number as **[00nn]** and **[0mmm]**.

### Station Name Setting (Console Only)

Pressing [DSS5] can change the setting of [Station Number] to be [Station Name]. During the setting of [Station Name], the following numerical key on Key Phone can be dialed as an English letter. Once the letter is entered to press [DSS3] can go back to the previous position or [DSS4] can go forward to the next position to set another letter.

<b>A</b> = [2]	<b>B</b> = [2][2]	<b>C</b> = [2][2][2]	<b>D</b> = [3]
<b>E</b> = [3][3]	<b>F</b> = [3][3][3]	<b>G</b> = [4]	<b>H</b> = [4][4]
<b>I</b> = [4][4][4][4]	<b>J</b> = [5]	<b>K</b> = [5][5]	<b>L</b> = [5][5][5]
<b>M</b> = [6]	<b>N</b> = [6][6]	<b>O</b> = [6][6][6]	<b>P</b> = [7]
<b>Q</b> = [1] or [7][7]	<b>R</b> = [7][7][7]	<b>S</b> = [7][7][7][7]	<b>T</b> = [8]
<b>U</b> = [8][8]	<b>V</b> = [8][8][8]	<b>W</b> = [9]	<b>X</b> = [9][9]
<b>Y</b> = [9][9][9]			
<b>Z</b> = [1][1] or [9][9][9][9]	Abbreviating dot " • " = [0]		

## Interrelation Zones: Program Zones 205 and 227

### P = 2 = Equipment Type (0 ~ 8) ---> "Equipment"

0 = No Equipment connected to this port

1 = Key Telephone without LCD and Handsfree

2 = Key Telephone with LCD and Handsfree

3 = Single Line Telephone

4 = Voice Service Channel

5 = DSS64 phone (only for UF-80/256)

6 = OHCA

7 = Voice Mail NOTE 28 (Unavailable for AV-8, NAV-8 and AV-16H)

8 = ISDN NOTE 29 (Only available for AV-64 and AV-256)

## INITIALIZATION

**NOTE 28:** Only available for SLT Station Port. The system will send the following In-Band DTMF Codes as soon as the assigned SLT answers the call under different conditions:

***Extension calls Voice Mail***

====→ [#] + [Extension Number]

***Call Forward All to Voice Mail***

====→ [\*] + [1] + [Ext. No. of ext. A]

***Call Forward Busy (or Busy TRF Back) to Voice Mail***

====→ [\*] + [2] + [Ext. No. of ext. A]

***Call Forward No Answer (or No Answer TRF Back) to Voice Mail***

====→ [\*] + [3] + [Ext. No. of ext. A]

***Call Transfer to Voice Mail***

====→ [\*] + [3] + [Ext. No. of ext. A]

**NOTE 29:** If the Port is connected to the ISDN interface, ISDN incoming calls to an internal station the system will send a special code **[A1]** to the assigned ISDN port as soon as the called station answers the call.

Interrelation Zones: None

phone, refer to **PROGRAM ZONE 500**.

Interrelation Zones: Program Zones 500

**P = 4 ~ 6 = Reserved for future use.**

**P = 7 = Restriction by Intercom Called.**

0 = Can be called by dialing extension number.

1 = Cannot be called by intercom but can still be transferred manually, or automatically when the call is put on hold.

2 = Cannot use Do Not Disturb function.

3 = Combine 1 + 2.

Interrelation Zones: None

## 503 Station Function - Grouping

Aristel ---

503	Station	GP	P				
1	1	1	0	0	0	0	0

AV

<-- Program Status Area

<-- P = 01~08 = Item

ST = Station Number

**P = 3 = Key group for DSS Phone = 1 ~ 8 ---> "DSS Key GP"**

To assign a specific group for Flexible DSS Keys on each DSS64

**Description: (P = 1 ~ 8)**

## INITIALIZATION

### **P = 1 = Station Group = 1 ~ 8 ----> "Station GP"**

Station Group is assigned for the following features:

- Zone Paging Group
- Called Pick Up Group
- Intercom Single Digit Group

**Interrelation Zones: Program Zones 209 and 401**

### **P = 2 = The 1st page of DSS Key group for key Phone = 1 ~ 8 ----> "KP Key GP"**

To assign a specific group for the first page of Flexible DSS Keys on each Key Telephone, refer to **PROGRAM ZONE 500 and 503-ST-8**.

**Interrelation Zones: Program Zones 500 and**

### **P = 3 = Dial 9 Group - 0 ~ 8 ----> "Dial 9 GP"**

The user dials [9] or [0] to get a free line from the assigned group in **PROGRAM ZONE 603**.

0 = Disable

1 = Search a free CO line in the 1st CO group

2 = Search a free CO line in the 2nd CO Group

.....

8 = Search a free CO line in the 8th CO group

**Interrelation Zones: Program Zones 202 and 603**

### **P = 4 = Incoming CO Group = 0 ~ 8 ----> "Incoming G"**

Allows the user to answer or pick up the incoming CO line according to **PROGRAM ZONE 608**.

**Interrelation Zones: Program Zones 608**

### **P = 5 = Toll Plan for Day = 0 ~ 9 ----> "Toll Day"**

Sets the Toll Plan (**00 ~ 09**) for Station on Day service. Refer to **PROGRAM ZONE 405**.

**Interrelation Zones: Program Zones 405**

### **P = 6 = Toll Plan for Night = 0 ~ 9 ----> "Toll Night"**

Sets the Toll Plan (**00 ~ 09**) for Station on Night Service. Refer to **PROGRAM ZONE 405**.

**Interrelation Zones: Program Zones 405**

**P = 7 = Reserved for future use.**


## INITIALIZATION

**P = 8 = The 2nd page of DSS Key group for Key Phone**  
**= "DSS Key GP"**

To assign a specific group for the second page of Flexible DSS Keys on each Key Phone. Refer to **PROGRAM ZONE 500 and 503-ST-2**.

Interrelation Zones: Program Zones 135, 500 and

### 504 Station Function - Station Level



←Program Status Area

<--P = 01~08 = Item

ST = Station Number

**Description: (P = 1 ~ 8)**

**P = 1 = Override Level = 0 ~ 9 ---> "Override"**

Allows the internal station to join in the conversation of another busy station by pressing [0] when busy tone is heard. A higher level can override the same or lower levels. Ten levels (0 ~ 9) are available (0 = the lowest level, 9 = the highest level).

9 = Can override levels 0 ~ 9

8 = Can override levels 0 ~ 8

.....

0 = Cannot override.

Interrelation Zones: System Administrator's Manual

**P = 2 = Monitor Level = 0 ~ 9 ---> "Monitor"**

Allows the internal station to secretly monitor the conversation of other busy stations by pressing [#] when busy tone is heard. Higher levels can monitor lower levels. Same levels cannot monitor each other. Ten levels are available (0 ~ 9). (0 = the lowest level - 9 = the highest level).

9 = Can monitor levels 0 ~ 8

8 = Can monitor levels 0 ~ 7

.....

0 = Cannot monitor.

Interrelation Zones: Program Zone 506-ST-07 and  
System Administrator's Manual

**P = 3 = Message Waiting Level = 0 ~ 9 ---> "DSS Key GP"**

Allows the internal station to pass the message signal to other busy or no answer stations by pressing [MSG] DSS function key when busy tone or ring back tone is heard. High levels can leave messages

## INITIALIZATION

to the same or lower level. Ten levels (0 ~ 9) are available. (0 = the lowest level - 9 = the highest level).

9 = Can pass Message Waiting to levels 0 ~ 9

8 = Can pass Message Waiting to levels 0 ~ 8

.....

0 = Cannot pass Message waiting.

**Interrelation Zones: Program Zone 212 and System**

**P = 4 = Station Loud bell = 0 ~ 1 ---> "DSS Key GP"**

- If the function is set for Loud Bell it allows the user to install an external Loud Bell interface if the working environment is very noisy. The Loud Bell will ring for all calls to the assigned station.
- If the function is set for Secret Recording, the system will open the function relay which is connected to the Tape recorder as soon as the assigned station handset (SLT or key phone) or Speaker On (for key phone only) is lifted, according to **PROGRAM ZONE 504-ST-6** and the Relay is set in **PROGRAM ZONE 302**.

0 = No Action

AV-8/AV-12

NAV-8/38

1 = Station Loud Bell for Relay 1 1 = Station Loud Bell for Relay 1

2 = Secret Recording for Relay 12 = Station Loud Bell for Relay 2

3 = Station Loud Bell for Relay 1

4 = Secret Recording for Relay 2

AV-64/256

1 = Station Loud Bell for Relay 1 2 = Station Loud Bell for Relay 2

3 = Station Loud Bell for Relay 3 4 = Station Loud Bell for Relay 4

5 = Secret Recording for Relay 16 = Secret Recording for Relay 2

7 = Secret Recording for Relay 38 = Secret Recording for Relay 4

**Interrelation Zones: Program Zone 302 and 504-ST-06**

**P = 5 = Station Ringing Frequency = 1 ~ 9 ---> "Ring Fre."**

1 = 1st Ringing Frequency 2 = 2nd Ringing Frequency

3 = 3rd Ringing Frequency 4 = 4th Ringing Frequency

.....

9 = 9th Ringing Frequency

**Interrelation Zones: System Administrator's Manual**

**P = 6 = Auto Secret Recording Function ---> "Security O"**

If the function is enabled the system will open the function relay connected to the Tape Recorder as soon as the assigned station

## INITIALIZATION

handset (SLT or key phone) is lifted or Speaker On (for key phone only) when the assigned station is enabled in **PROGRAM ZONE 504-ST-4** and the Relay is set for Secret Recording in **PROGRAM ZONE 302**.

0 = Disable Auto Secret Recording function  
1 = Enable Auto Secret Recording function

Interrelation Zones: Program Zone 302 and 504-ST-4


**P = 7 = Reserved for future use.**

**P = 8 = System Wide CFW Function**

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 242

## 505 Station Function - General Function 1



**Description: (P = 1 ~ 8)**

**P = 1 = Paging Function = 0 ~ 1 ----> "Paging"**

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 503-ST-1

**P = 2 = Be Paged Function = 0 ~ 1 ----> "Be Paged"**

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 302 and 503-ST-1

**P = 3 = Hold Function = 1 ~ 1 ----> "Hold Func"**

0 = Disable      1 = Enable



## INITIALIZATION

**Interrelation Zones: None**

### **P = 4 = Manual Line = 0 ~ 1 ---> "Manual"**

If the function is set, lifting the handset or pressing [SPK] will automatically call the consoles which the console group number is the same as the station group number of the calling station without dialing any digits.

0 = Disable      1 = Enable

**Interrelation Zones: Program Zone 400 and 503-ST-1**

### **P = 5 = Call Split Function = 0 ~ 1 ---> "Call Split"**

This function enables a station to talk to two parties simultaneously.  
**(the function is worked for Single Line Telephone only)**

0 = Disable      1 = Enable

**Interrelation Zones: System Administrator's Manual**

### **P = 6 = System Alarm Function = 0 ~ 1 ---> "SYS. Alarm"**

Allows the assigned station to receive the alarm signal as soon as the

system alarm time is reached.

0 = Disable      1 = Enable

**Interrelation Zones: Program Zone 305 and 505-ST-7**

### **P = 7 = System/User Alarm Signal = 0 ~ 1 ---> "Alarm Sig."**

0 = Background Music      1 = Do Not Disturb Tone


**Interrelation Zones: Program Zone 305, 505-ST-6 and**

### **P = 8 = Security Function = 0 ~ 1 ---> "Security"**

0 = Unlocked **(Can make outgoing calls)**

1 = Locked by Security Code **(Cannot make outgoing calls)**

**Interrelation Zones: System Administrator's Manual**

**506 Station Function - General Function 2**

&lt;--Program Status Area

&lt;--P = 01~08 = Item

ST = Station Number

**Description: (P = 1 ~ 8)**

**P = 1 = System Engineering Password Capability = 0 ~ 1 ----> "System PSW"**

Determines whether the station can enter the system programming by using the engineering password.

0 = Cannot            1 = Can

**Interrelation Zones: Program Zone 235 and 301-01**

**P = 2 = Disable Intercom Dialing = 0 ~ 1 ----> "ICM Dial D"**

If function enabled the station cannot make an intercom call by dialing a station number. It can however still make an intercom call by pressing a Flexible DSS Station key or using the Single Digit Dialing function.

**0 = Disabled = Station can make an intercom call by dialing the station number.**

**1 = Enabled = Station cannot make an intercom call by dialing the station number.**

**Interrelation Zones: None**

**P = 3 = Key Tone = 0 ~ 1 "Key Tone"**

0 = Key Phone without Key Tone can be heard during dialing.

1 = Key Phone with Key Tone can be heard during dialing.

**Interrelation Zones: None**

**P = 4 = Volume Up Function = 0 ~ 1 ----> "Volume Up"**

If function is enabled the assigned key station ringing volume will be gradually increased when called.

0 = Disable            1 = Enable

**Interrelation Zones: None**

## INITIALIZATION

### **P = 5 = Intercom Busy Reminder Tone Capability**

**= 0 ~ 1 ---> "ICM Tone"**

If function is enabled the assigned station will hear a **Busy Reminder Tone** during intercom call or transferred when it is engaged.

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 122 and 229

### **P = 6 = Incoming Ringing Auto Answer**

**= 0 ~ 1 ---> "CO Answer"**

If function is enabled the assigned station can pick up incoming calls on another station by lifting the handset, even if not allowed to answer in **PROGRAM ZONE 600** or **601**.

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 600 and 601

### **P = 7 = Environment Monitoring Function**

**= 0 ~ 1 ---> "Monitor St"**

If function is enabled the assigned station can listen to the surrounding area of the lower level handsfree key station. The Level setting is the same as **Zone 504-ST-02**. Refer to System Administrator's Manual for operation method.

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 504-ST-2 and

### **P = 8 = Auto Answer Paging = 0 ~ 1 ---> "Page Ans."**

If the function is enabled, the assigned station can answer Paging automatically by lifting the handset **(for both Single Line Telephone and Key Telephone)** or pressing [SPK] **(only for Key Telephone)**.

0 = Disable      1 = Enable

Interrelation Zones: Program Zone 502-ST-2

## 507 Station Function - General Function 3

Aristel ---

507	Port	No	P
CSN	LD	FC	

AV

&lt;--Program Status Area

&lt;--P = 01~03 = Item

ST = Station Number

Description: (P = 1 ~ 3)

P = 1 = Port Number = CSN ----&gt; "Port No"

- CSN here is the same as in **PROGRAM ZONE 502-CSN-IP**.
- For checking only. The user cannot change the parameter.

Interrelation Zones: None

P = 2 = Call Limit Time Duration = LD

= 00 ~ 99 minutes ----&gt; "Call Limit"

When the assigned time is reached this function inhibits the external call duration according to the limitation pattern in **PROGRAM ZONE 224**

Interrelation Zones: Program Zone 224

P = 3 = Forced Account Code = FC NOTE 30 ----> "FAC Code"

Allows the user to be temporarily unrestricted during outgoing dialing by using Forced Account Number code which is the same as the assigned code in **PROGRAM ZONE 403**.

If the setting is **00**, all Forced Account Numbers are allowed.

**NOTE 30:**

AV-8/NAV-8	----	FC = 00 ~ 26
AV-12/38	----	FC = 00 ~ 26
AV-64	----	FC = 00 ~ 64
AV-256	----	FC = 00 ~ 99

Interrelation Zones: Program Zone 403

P = 4 ~ 8 = Reserved For Future Use.

## 508 Station Function - Hot Line

Aristel ---

508	HOT	CO
SSSS		


AV

&lt;--Program Status Area

&lt;--ST = Station Number

= 2 ~ 4 digits

## INITIALIZATION



<--Program Status Area  
<--ST = Station Number  
= 2 ~ 4 digits

## Interrelation Zones: Program Zone 404

508	HOT	CO
18	ST:11	

11 = Station No.  
18 = The called station number

### Description:

- Allows the user to dial a specific external number through System Speed Dial, or an internal station by lifting the handset.
- Press **[DSS5]** to change the mode to be SPD or Station Number.
- Press **[SPK]** for normal dialing.
- Enter a SPD code (**100~354 only**) for outgoing call or a Station number for Intercom call.

### EXAMPLE:


508	HOT	CO
SPD:101	ST:11	

11 = Station No.

SPD:101= Speed Dial Code 101 (for example:  
00886285123000)

When station 11 handset is lifted the system will automatically access a free CO line according to SPD Code 101 and dial the number "00886285123000"

## 509 Station Function - Individual SPD Block



<--Program Status Area  
<--ST = Station Number  
= 2 ~ 4 digits  
AA = Block 1  
= For Individual SPD  
Codes 00~09  
BB = Block 2  
= For Individual SPD  
Codes DSS1~10

### Description:

Divides the sets of Individual Speed Dial Codes into a different system memory block. Two (2) kinds of block can be set; one for code "00 ~ 09" and the other for "DSS1 ~ DSS10". The setting

## INITIALIZATION

value for each block must be according to the total sets of Individual Speed Dial Codes in **PROGRAM ZONE 225** NOTE 31. Each block includes 10 sets of Individual Speed Dial Codes.

### NOTE 31:

#### ZONE 227 = 0

Setting Value in Zone 225	AV-8/NAV-8/ AV-12/AV-38		AV-64/AV-256	
	AA	BB	AA	BB
0	00 ~ 60	00 ~ 60	00 ~ 98	00 ~ 98
1	00 ~ 50	00 ~ 50	00 ~ 98	00 ~ 98
2	00 ~ 40	00 ~ 40	00 ~ 90	00 ~ 90
3	00 ~ 30	00 ~ 30	00 ~ 80	00 ~ 80
4	00 ~ 20	00 ~ 20	00 ~ 70	00 ~ 70
5	00 ~ 10	00 ~ 10	00 ~ 60	00 ~ 60
6	00 ~ 10	00 ~ 10	00 ~ 50	00 ~ 50
7	00 ~ 10	00 ~ 10	00 ~ 40	00 ~ 40
8 ~ 9	00 ~ 10	00 ~ 10	00 ~ 30	00 ~ 30

#### ZONE 227 = 1

Setting Value in Zone 225	AV-8/NAV-8/ AV-12/AV-38		AV-64/AV-256	
	AA	BB	AA	BB
0	00 ~ 25	00 ~ 25	00 ~ 50	00 ~ 50
1	00 ~ 15	00 ~ 15	00 ~ 40	00 ~ 40
2	00 ~ 05	00 ~ 05	00 ~ 30	00 ~ 30
3	00 ~ 05	00 ~ 05	00 ~ 20	00 ~ 20
4 ~ 9	00 ~ 05	00 ~ 05	00 ~ 10	00 ~ 10

- Each Station can use up to two blocks (20 sets of Individual Speed Dial Codes.)
- Each Station in the same block will share the same Speed Dial Code.

### EXAMPLE:

509	Indivi.	SPD
01 02		ST:11

**11 = Station No.**

[01, 02] = Station 11 can use block **01** and **02** for Individual SPD (20 sets; 10 sets for "00 ~ 99", another 10 sets for "DSS1 ~ DSS10")

509	Indivi.	SPD
04 00		ST:12

**12 = Station No.**

[04, 00] = Station 12 can use block **04** for Individual SPD ( only 10 sets for "00 ~ 99", **00 = for no block**)

509	Indivi.	SPD
04 02		ST:13

**13 = Station No.**

[04, 02] = Station 13 can use block **04** and **02** for Individual SPD (20 sets; 10 sets for "00 ~ 99" **are shared with Station 12**, another 10 sets for "DSS1 ~ DSS10" **are shared with Station 11**)


Interrelation Zones: Program Zone 225 and 227
---

---

**510 ~ 599      Reserved For Future Use**

## ■ CO Function (Zone 600 ~ 699)

### 600 Incoming Ringing Assignment - Day Time



<--Program Status Area  
 <--CO = CO Number NOTE 32  
 IP=Cursor Position=01~16  
 SS=Station Number  
 =2~4 digits

Def.=[11 12 13 14 15 16 17 18]

#### Description:

Assigns incoming ringing stations on Day time. The assigned stations can answer incoming calls directly by lifting the handset during ringing. There are four (4) different ringing methods; (**LINEAR**, **CIRCULAR**, **HUNT** and **COMMON AUDIBLE**) NOTE 32

- If the Voice Channel is used for DISA line in AV-64/256, it is necessary to assign the Voice Channel Number here to be the incoming ringing station. For AV-16H/AV-24/AV-38 the Voice Channel Number is assigned in **PROGRAM ZONE 609**.

#### NOTE 32:

1. **AV-8/NAV-8**---> CO = 01 ~ 03  
**AV-12** ---> CO = 01 ~ 04  
**AV-38** ---> CO = 01 ~ 12  
**AV-64** ---> CO = 01 ~ 20  
**AV-256** ---> CO = 01 ~ 40

2. The different ringing methods:

#### **COMMON AUDIO RING:**

All assigned stations will ring at the same time.

#### **LINEAR RING:**

The incoming line will always ring to the 1<sup>st</sup> assigned station and will then ring to the next free station immediately and automatically after ringing to the busy station.

#### **CIRCULAR RING:**


The first incoming line will ring to the 1<sup>st</sup> assigned station, the second incoming line will ring to the 2<sup>nd</sup> assigned station. The incoming line will automatically ring to the next free station immediately.

#### **HUNT RING:**

An incoming line will always ring to the 1<sup>st</sup> assigned station. If the station is busy it will then automatically ring to the next free station immediately. If that station does not answer it will then ring to the next free station as soon as the Incoming Hunt Ringing Time in **PROGRAM ZONE 123** is reached.

Interrelation Zones: Program Zones 123, 306,  
308, 402, 502-CSN-1, 506-ST-6,  
604-CO-7 and 609

## 601 Incoming Ringing Assignment - Night Time



<--Program Status Area  
<--CO = CO Number NOTE 32  
IP=Cursor Position=01~16  
SS=Station Number  
=2~4 digits  
Def.=[11 12 13 14 15 16 17 18]


### Description:

The same function as **PROGRAM ZONE 600** but for Night Time Service.

- **601-CO-09 (~16), only available in AV-8/NAV-8**  
If Midday Time is enabled, the incoming CO lines must ring to the stations here even though such CO lines are not set as DISA line when A3VSCA is existed.

Interrelation Zones: None

## 602 Door Ring Assignment



<--Program Status Area  
<--GP = Door Phone  
Number NOTE 33  
IP=Cursor Position=01~08  
SS=Station Number  
=2~4 digits  
Def.=[11 12 13 14 15 16 17 18]

### Description:


The stations assigned here will ring for 30 seconds when the Door Phone call is activated.

**NOTE 33:** AV-8/AV-12 --->GP = 01  
NAV-8 --->GP = 01 ~ 02  
AV-38 --->GP = 01 ~ 02  
AV-64/AV-256 --->GP = 01 ~ 02

Interrelation Zones: Program Zones 124, 131, 244,  
249, 302 and 303



## 603 CO Group Assignment



<--Program Status Area

<--GP = CO Group

Number (01~08)

IP=Cursor Position

SS=CO Number Refer to NOTE

32, Point 1.

Def.= [01 ~ 40]

### Description:

The assigned CO lines can be accessed by the station which **PROGRAM ZONE 503-ST-3** is the same as the group number here by pressing [9] or [0], or pressing DSS CO line key or by using Speed Dial.

- **603-05-IP**

Station presses [ \* 5 ] will access a free CO line here automatically. It will not be effected by the DIAL [9] (or [0]) group in **PROGRAM ZONE 503-ST-3**.

- **603-06-IP**

Station presses [ \* 6 ] will access a free CO line here automatically. It will not be effected by the DIAL [9] (or [0]) group in **PROGRAM ZONE 503-ST-3**.

- **603-07-IP**

Station presses [ \* 7 ] will access a free CO line here automatically. It will not be effected by the DIAL [9] (or [0]) group


in **PROGRAM ZONE 503-ST-3**.

- **603-08-IP**

Station presses [ \* 8 ] will access a free CO line here automatically. It will not be effected by the DIAL [9] (or [0]) group in **PROGRAM ZONE 503-ST-3**.

Interrelation Zones: Program Zones 202, 215,

## 604 CO Function Assignment



<--Program Status Area

<--P=Cursor Position=1~8

CO=CO Number Refer to NOTE

32, Point 1.

Def.= [ 01003000 ]

### Description:

**P = 1 = CO Type = 0 ~ 1 ---> "CO Type"**

0 = Centrex line

1 = Installed behind PABX

3 = ISDN Line, the "3" is given by the system automatically once the system detects ISDN card is existed, and the detection of CLI and DID from ISDN line will be automatic detection, too. Refer to A2DTKA

## INITIALIZATION

5 = Caller ID (CLI) Refer to UF-CND Operation Manual

**Interrelation Zones: Program Zones 200 and 202**

**P = 2 = Outgoing Dialing Signal = 0 ~ 1 ---> "Pulse/Tone"**

0 = Pulse signal and DISA Enable Time is according to **PROGRAM ZONE 118.**

1 = Tone signal and DISA Enable Time is according to **PROGRAM ZONE 118.**

2 = Pulse signal and DISA Enable Time is according to **PROGRAM ZONE 140.**

3 = Tone signal and DISA Enable Time is according to **PROGRAM ZONE 140.**

4 = Pulse signal and DISA Enable Time is according to **PROGRAM ZONE 141.**

5 = Tone signal and DISA Enable Time is according to **PROGRAM ZONE 141.**

6 = Pulse signal and DISA Enable Time is according to **PROGRAM ZONE 142.**

7 = Tone signal and DISA Enable Time is according to **PROGRAM ZONE 142.**

**Interrelation Zones: Program Zones 101, 118, 140,**

**P = 3 = DISA/ECF Capability = 0 ~ 8 ---> "DISA"** NOTE 34

0 = Day Disable	Night Disable
1 = Day Disable	Night "DISA" Enable
2 = Day "DISA" Enable	Night Disable
3 = Day "DISA" Enable	Night "DISA" Enable
4 = Day Disable	Night "ECF" Enable
5 = Day "ECF" Enable	Night Disable
6 = Day "ECF" Enable	Night "ECF" Enable
7 = Day "DISA" Enable	Night "ECF" Enable
8 = Day "ECF" Enable	Night "DISA" Enable

**Interrelation Zones: Program Zones 116, 117, 118, 119, 218, 219, 301-03, 306, 402**

**P = 4 = ECF Capability (Night Transfer) = 0 ~ 9 ---> "ECF"**

0 = Disable ECF Capability
1 = ECF by Speed Dial Code 101
2 = ECF by Speed Dial Code 102
.....

## INITIALIZATION

9 = ECF by Speed Dial Code 109

**Interrelation Zones: Program Zones 404 and 604-CO-3**

**P = 5 = Pick Up Capability = 0 ~ 3 ---> "Pick Up"**

0 = Day Disable	Night Disable
1 = Day Disable	Night Enable
2 = Day Enable	Night Disable
3 = Day Enable	Night Enable

**Interrelation Zones: Program Zones 600 and 601**

**P = 6 = CO Loud Bell = 0 ~ 9<sub>NOTE 35</sub> ---> "Loud Bell"**

If the operational environment is very noisy an external Loud Bell can be installed to the Relay interface. Incoming calls to the system through the assigned CO line will be heard from the Loud Bell.

0 = Disable  
1 = Enable the 1<sup>st</sup> Relay  
2 = Enable the 2<sup>nd</sup> Relay  
.....  
9 = Enable the 9<sup>th</sup> Relay

**Interrelation Zones: Program Zones 302, 600**

**P = 7 = Incoming Ringing Method for Day**

**= 0 ~ 4 ---> "Ring MTD-D"** Refer to NOTE 32, Point 2.

0 = Common Audio on the stations assigned in **PROGRAM ZONE 600 (601)**.

1 = Linear Ringing on the stations assigned in **PROGRAM ZONE 600 (601)**.

2 = Circular Ringing on the stations assigned in **PROGRAM ZONE 600 (601)**, and also for the stations assigned in **PROGRAM ZONE 607-GP-IP**.

3 = Hunt Ringing on the stations assigned in **PROGRAM ZONE 600 (601)**.

4 = Hunt Ring on the stations assigned in PROGRAM ZONE 600 (601), if the called station is busy the Busy Reminding Tone will be heard by the called station and the cycle of Busy Reminding Tone is according to the PROGRAM ZONE 122, and the call will be transferred to the next free station as soon as the Hunt Ring Time in PROGRAM ZONE 123 is reached. If the called station is free then keep the same operation function as PROGRAM ZONE 604-CO-7 =

3.

(The function is only available in AV-38 and AV-256)

## INITIALIZATION

Interrelation Zones: Program Zones 122, 123, 600

### **P = 8 = Incoming Ringing Method for Night**

**= 0 ~ 4 ---> "Ring MTD-N"** Refer to NOTE 27, Point 2.

0 = Common Audio

1 = Linear Ringing

2 = Circular Ringing

3 = Hunt Ringing

**4 = Hunt Ring, if the called station is busy the Busy Reminding Tone will be heard by the called station and the cycle of Busy Reminding Tone is according to the PROGRAM ZONE 122, and the call will be transferred to the next free station as soon as the Hunt Ring Time in PROGRAM ZONE 123 is reached. If the called station is free then keep the same operation function as PROGRAM ZONE 604-CO-8 = 3.**

Interrelation Zones: Program Zones 122, 123, 600

**NOTE 34:** There are three (3) different sub-functions included in DISA (**Direct Inward Station Access**) function:

#### **1. Normal DISA for calling internal station:**

##### **1-1. Silence DISA:**

Incoming calls to the system through DISA line which does not have Voice reminder Service will hear system dial tone after the system answers the call and can call internal stations by dialing the called station number.

##### **1-2. Voice Service DISA:**

line which is provided by Voice Reminder Service will hear the voice reminder service after the system answers the call and can call internal stations by dialing the called station number.

#### **2. Special DISA for another outgoing call:**

Incoming calls to the system through DISA line, regardless of which Silence or Voice Reminder Service, can **dial [9] (or [0]) + [DISA PASSWORD]** to access another free CO line. Once the CO line dial tone is heard the caller can dial the desired number for another outgoing call.


#### **3. External Call Forward (ECF) function:**

Incoming calls to the system through DISA line, regardless of which Silence or Voice Reminder Service, will automatically access another free CO line according to **PROGRAM ZONE 404 and 604-CO-4.**

- The call duration in Points 2 and 3 will be limited by **PROGRAM ZONE 119** and callers can add another duration cycle by pressing any numerical digit whilst hearing time limit reminding tone. **Pressing [#] during the call will allow the numbers to be re-entered or press [\*] to release both CO lines.**

**NOTE 35:** AV-8/AV-12 ---> CO Loud Bell = 01  
 NAV-8 ---> CO Loud Bell = 01 ~ 02  
 AV-38 ---> CO Loud Bell = 01 ~ 02  
 AV-64 ---> CO Loud Bell = 01 ~ 04  
 AV-256 ---> CO Loud Bell = 01 ~ 09

## 605 CO Lock



<--Program Status Area  
 <--IP=CO Number Refer to NOTE 32,  
 Point 1.  
**S=0 ~ 3**  
**Def.= [ 0 0 0 0 0 0 0 ]**

### Description:

There are four (4) different conditions which can be selected for CO line Lock function.

S = 0 = Unlock both incoming and outgoing


S = 1 = Lock outgoing, unlock incoming.

S = 2 = Lock both outgoing and incoming and turn CO LED OFF.

S = 3 = Lock both outgoing and incoming and turn CO LED ON.

Interrelation Zones: None

## 606 CO Incoming Ringing Frequency Assignment



<-- Program Status Area  
 <-- IP=CO Number Refer to NOTE 32,  
 Point 1.  
**S=0 ~ 9**  
**Def.= [ 0 0 0 0 0 0 0 ]**

### Description:

Enables the user to recognize the different incoming ringing frequencies. Nine (9) different ringing frequencies can be selected for each CO line.

S = 0 = According to the Station Ringing Frequency

S = 1 = The 1<sup>st</sup> ringing frequency level; 447.5Hz±419.5Hz

S = 2 = The 2<sup>nd</sup> ringing frequency level; 516.4Hz±447.5Hz

S = 3 = The 3<sup>rd</sup> ringing frequency level; 559.4Hz±479.5Hz

S = 4 = The 4<sup>th</sup> ringing frequency level; 610.2Hz±479.5Hz

S = 5 = The 5<sup>th</sup> ringing frequency level; 671.3Hz±479.5Hz


S = 6 = The 6<sup>th</sup> ringing frequency level; 745.9Hz±516.4Hz

S = 7 = The 7<sup>th</sup> ringing frequency level; 839.0Hz±610.2Hz

S = 8 = The 8<sup>th</sup> ringing frequency level; 959.0Hz±671.3Hz

S = 9 = The 9<sup>th</sup> ringing frequency level; 1118.8Hz±839.0Hz

## 607 Single Digit Group For DISA Dialing



<--Program Status Area  
 <--GP=Group Number  
     =Single Digit=1~5 & 7~8  
 IP=Cursor Position=01~08  
 SSS=Station Number  
     =2 ~4 digits  
 Def.= [ 000 000 000 000 ]

### Description:


A maximum of seven (7) groups (GP = 01 ~ 05, and 07 ~ 08) can be assigned.

- Group 6 cannot be used in this function.
- GP = 01 ---> Single Digit 1.  
     GP = 02 ---> Single Digit 2.  
     .....  
     GP = 05 ---> Single Digit 5.  
     GP = 07 ---> Single Digit 7.  
     GP = 08 ---> Single Digit 8.
- The stations in the group are the called stations when the external

caller dials the representative Single Digit through DISA line. To call a specific station the caller can dial **[6] + [Station Number]**.

Interrelation Zones: Program Zone 238

## 608 Incoming CO Line Group



<--Program Status Area  
 <--GP=Group Number=01~08  
 IP=Cursor Position  
 SS=CO Number<sup>Refer to NOTE</sup>

32, Point 1.


Def.= [ 01 ~ 40 ]

### Description:

The assigned CO lines can be answered by the station which has the same Incoming CO line Group in **PROGRAM ZONE 504-ST-4**.

**(Not available in AV-8 and NAV-8.)**

Interrelation Zones: Program Zone 222 and 504-ST-4

**609 Voice Channel For Different CO Line**

<--Program Status Area  
 <--IP=CO Number Refer to NOTE 32,  
 Point 1.  
 S=0 ~ 2  
 Def.= [ 00000000 ]

**Description:**

Allows the user to assign the Voice Channel Number for each incoming CO line.


**(Only available in AV-38)**

0 = Incoming line can be answered by both Voice Channels **(Number 63 and 64)**.

1 = Incoming line can be answered by the 1<sup>st</sup> Voice Channel **(Number = 63)** only.

2 = Incoming line can be answered by the 2<sup>nd</sup> Voice Channel **(Number = 64)** only.

Interrelation Zones: Program Zone 504-ST-4

**610 ISDN DID Number**


<--Program Status Area  
 <--NNN=DID Code  
     =001~255 NOTE 36  
 IP=Cursor Position  
 SSS=DID Number  
 Def.= [ 000 ]

**Description:**

ISDN allows a single line to have multiple phone numbers. So an individual phone number can be allocated to an internal station, saving the receptionist from taking all incoming calls. This is known as Direct Inward Dialing (DID). The conversion list of phone numbers to stations is known as the ISDN DID Station Lookup in **PROGRAM ZONE 611**. The last two (or three) digits in the called number are used to find an internal station number in **PROGRAM ZONE 611**. If an incoming call doesn't match any the entries in the table, then all stations ring according to **PROGRAM ZONE 600 (601)**. Up to 255 entries can be used.

Interrelation Zones: Program Zone 404-SSS-IP, 600,

## 611 ISDN DID Station Lookup



<--Program Status Area

<--NNN=DID Code

=001~255<sup>NOTE 36</sup>

IP=Cursor Position

SSS=Station Number

Def.= [ 000 ]

### Description:

The assigned station will be ringing if the DID Code is matched with the DID Code in **PROGRAM ZONE 610**.


### NOTE 36:

ISDN DID Function	In AV-64 System	In AV-256 System
Without DID Name Display	NNN → NN=01~99	NNN=001~255
With DID Name Display	NNN → NN=01~99	NNN=001~154
	ZONE 404-SSS-IP SSS = 201 ~ 299	ZONE 404-SSS-IP SSS = 201 ~ 354

will detect the **LAST 2 (or 3) DIGITS (DID Number)** of the called number.

**Step 2.** System will find the DID Number is assigned in which DID Code in **PROGRAM ZONE 610-NNN-IP** and compare with the DID Code in **PROGRAM ZONE 611-NNN-IP**. If there is any station assigned in **PROGRAM ZONE 611-NNN-IP**, then the call will ring to that assigned stations and proceed the Step 3; otherwise, the call will ring to the assigned stations in **PROGRAM ZONE 600 (or 601)**.

**Step 3.** If the assigned station is LCD Key Phone the system will go to **PROGRAM ZONE 404-SSS-IP** to find the Name assigned for that DID number and displays it on the LCD as the following:




**Interrelation Zones: Program Zone 404-SSS-IP, 600, 601 604-CO-1 = 3 and 610**

### OPERATION EXAMPLE:

**Step 1.** System receives a DID incoming call through the ISDN line



## 612 ISDN Termination



<--Program Status Area

<--IP=CO Number<sub>Refer to NOTE 32,</sub>

Point 1.

S=0 ~ 1

Def.= [ 000000000000 ]

### Description:

Multiple devices can share an ISDN cable (known as an S-Bus). But the last device must have a 'termination resistor' fitted. This helps prevent errors on the cable, making the link more reliable. And because the A2DTKA card is likely to be the only device on the S-bus, then by default they should have their 'termination resistor' fitted. The A2DTKA has software control of the 'termination resistor.' This control is done through the AV-64 and AV-256 systems. Each S-bus connection on the card can be controlled separately.


(Only available in AV-64/AV-256)

0 = Un-terminated

1 = Terminated

Interrelation Zones: None

## 613 ISDN Type



<--Program Status Area

<--IP=CO Number<sub>Refer to NOTE 32,</sub>

Point 1.

S=0 ~ 2

Def.= [ 00000000000 ]

### Description:

The A2DTKA is designed to operate on different types of ISDN.

0 = Telstra MicroLink (Australian Specific Standard)

1 = Telstra OnRamp (EURO ISDN Standard)

2 = Taiwanese ISDN

NOTE 37: 1. You are recommended to setup "1" (default) first, if can not work then change to be "2", if still can not work then change to be "0". If all the above 3 setting values can not work in your location, please provide us your detail ISDN specification.

2. CO lines are paired to make an S-bus. For example: if you set C03 to OnRamp, then you should also set CO4 to OnRamp.

Interrelation Zones: None

---

614 ~ 699

Reserved For Future Use